# **ANS Data**

# **Transmission Standard**

Version 4.3 – 03<sup>rd</sup> June 2020

#### **Note for Developers**

Fields recorded in the Standards Document are available for use, however it does not necessarily mean that they are active in all software systems. Before implementing any new fields within your software please check with the software providers your systems will be communicating with to ensure that the field/'s are in active use.

# Contents

Document Modifications	3
Introduction	5
Message Format	5
Message Acknowledgements	6
Example Messages	6
Initial Job Dispatch (JO – JR)	6
Request for Revised ETA (JO - JR)	7
Revised ETA Response (JR – JO)	7
Request for Revised ETC (JO - JR)	7
Revised ETC Response (JR – JO)	7
Request for ATA (JO - JR)	7
ATA Message (JR – JO)	7
Acceptance of Job (JR - JO)	7
Refusal of Job (JR - JO)	8
Cancellation of Job (JO – JR)	8
Job rebooked (JR – JO)	8
Technician Notified Update (JR – JO)	8
Technician Accepted Update (JR – JO)	8
On Route Update (JR – JO)	8
On Scene Update (JR – JO)	8
Request for authorisation (JR – JO)	8
Job Clear-down (JR – JO)	9
Job Invoice (JR – JO)	9
Vehicle Location Data (JR – *)	10
Request for Drivers Location (JO - JR)	10
Response to Drivers Location Request (JR- JO)	10
Request for the next job image (JO - JR)	10
Response to Image Request (JR- JO)	10
Message Fields	10
Fields 0000 – 1000: Charge related data	10
Fields 1000 – 1100: Job Recipient Details	13
Fields 1100 – 1300: Job Details	19
Fields 1700 – 1799: Support record types	34
Fields 2000 – 2999: Vehicle Telemetry Data	34
Fields 9000 – 9999: Miscellaneous record types	34
Glossary	
Appendix A – Quick Reference	37

Appendix B – Process Diagrams	40
Standard Job Process	40
Job Cancellation Process	42
Job Additional Authorisation Process	43
Job Rebook Process	44
Request for ATA Process	45
Request for Revised ETA Process	46
Request for Revised ETC Process	46
Job Rebooked by JR Process	46
Appendix C - Vehicle Breakdown Incident Message Flow	48
Initial Job Transmission	48
Job Acceptance	48
Job Rejection	48
Job Cancellation	49
Revised ETA Request / Response	49
Request for ATA and Response	49
Authorisation Request	49
Job updates from JR to JO	50
Job rebooking by a JR	50
Job Completion by a JR	50
Job Invoicing	50
Job Status Point Definitions	51
Issued (or Technician Notified)	51
Technician Accepted	51
On Route	51
At Scene	51
Clear (scene)	51
Complete	51
Back to Base	51
Industry Standard Symptom Codes	52
Industry Standard Fault Codes	53
Industry Standard Secondary Fault Codes	61
Industry Standard Outcome Codes	62

# **Document Modifications**

Date	Modification User	Version	Modification
2013-03-07	Chris White	VEISIOII	1752 – Software version added
2013-03-07	Chris white		
			1216 – Postcode added
2042.06.24	Cl.: Milit		Version 1.3 DRAFT:
2013-06-21	Chris White		Amended 1213 Description
			1020 example updated (comma removed)
			Redundant 1229 field removed
			1227 now earliest date/time
			1228 now later date/time
			Priority flag moved to 1240
			Priority reason added
			Added Appendix E Quick Reference
	Nigel Ashton		Added new headers to 9100
			1230/1231 added
			Example of rebook added
			1250/1251/1252 added
			Authorisation request added
			1260/1261 added
			Updated ETA Request example
			XXX-UPE example added
			ATA request example added
			ETA response example added
			Version 1.4 DRAFT
2013-10-10	Chris White		1270 – Axle Type added
			1271 – No of Doors added
			1272 – Year of registration added
			1273 – Vehicle Height added
			1274 – Vehicle Width added
			1275 – Vehicle Length added
			1276 – Trailer type added
			1277 – Towed Item Axle Type added
			1277 – Towed Item Axie Type added
			1279 – Towed Item Width added
			1280 – Towed Item Length added
			1281 – Towed Item Weight added
			1282 – Towed Item Load description added
			1283 – Prebook reason added
			1284 – Prebook Detail added
			1242 – Priority Detail added
			1021 – Technician Accepted added
			1022 – Technician Location added
			1217 – Customer outcome added
			1104 – Amended
			1203 – Amended
2013-10-14	Apex		Clarified Response Message
			APX-TIM Example removed (redundant)
			0000 remarks amended
			0002 Mileage reworked.
			0005 Hours reworked.
			1214 amended to be deprecated.
			1227 and 1228 description altered
			1230 changed to optional
			1261 removed. (Redundant)
			9100 updated.
			9999 record in examples corrected
			1217,1219,1242,1270,1284 set as 'New' Fields
2013-10-29	Andy Marks		MTS-COMP changed to MTS-CLR for cleardown message type
7012-10-72	Alluy Ividiks		I MITS COMIT CHAINED TO MITS CENTROL CHEATHOWITHESSARE LYPE

2013-10-29		1021, 1022, 1023 changed to be technician notified, accepted and location
		coordinates accordingly
2013-11-15	Andy Marks	Changed the RAU message to remove the mileage field as this can be achieved in
		the requested items list.
		Added the notes field to the RAU message to allow supporting text to be sent with
		those authorisation requests
		Removed redundant 1251 field.
		Allow 1252 (Requested items for authorisation) to be repeated 5 times for each
		different item
		Removed HRS and DES from the list of requested items as there's no field to send
		the requested information back in the response message.
2013-11-26	Andy Marks	Re-enable field 1016 for a new purpose – to supply some supporting text when
2012 11 27		sending an updated ETA back.
2013-11-27	Andy Marks	Add list of customer outcome codes
2012 12 12		Add list of subsequent resource codes
2013-12-19	Andy Marks	Redesign document, added workflow diagrams and description
2014-01-22	Andy Marks	Added second resource flag field 1222
2014-03-18	Andy Marks	Added industry standard fault / outcome codes list as appendix
2014-05-01	Andy Marks	Added timestamp to technician location field
2014-06-12	Andy Marks	Re-format document to make it shorter
2014-06-12	Andy Marks	Re-Enable / Rename 1017 field for 'Images Required' flag
2014-06-12	Andy Marks	Re-Enable / Rename 1019 field for 'Image Count' field
2014-06-12	Andy Marks	Re-Enable 1215 ring on approach field and change to Y/N flag
2014-06-12	Andy Marks	Rename 'Drivers Phone Number' to 'Main Phone Number'
2014-06-12	Andy Marks	Re-Enable field 1225 as 'Alternative Phone Number'
2014-06-19	Andy Marks	Add minutes to Ring On Approach field (1215)
2014-06-19	Andy Marks	Change field 1106 Odo Reading to be to / from club instead for to club
2014-06-19	Andy Marks	Colour the statuses, rename a few fields to make them clearer, general tidy up.
2014-07-15	Andy Marks	Rename 1017 to 'UTC time' from 'Images Required' and add field 1024 for 'Images Required'
2014-07-31	Andy Marks	Updated the 1020 field definition and examples to include comma between date and time strings.
2014-09-08	Andy Marks	Updated some of the example messages
2014-10-16	Andy Marks	Added new customer outcome code 'CUSTCONT'
2014-12-12	Andy Marks	Correct some errors in the examples, extend 1209 and 1211 to 100 chars
	1	Version 2.1:
2015-06-04	Chris White	Added NS04 Outcome Code
2015-07-30	Andy Marks	Added 1224 and 1226 records to store the accuracy of location and destination
		lat/Ing contained in fields 1213 and 1221
2015-10-20	Andy Marks	Extend date on deprecated fields 1108,1103,1214 to March 2016
2015-10-20	Andy Marks	Add 'OTH' priority reason code
2015-10-20	Andy Marks	Add FUE074 & FUE075 for AdBlue misfuels to fault codes list
2015-10-21	Andy Marks	Add LGV011 for Exhaust Brake to fault codes list
2015-10-21	Andy Marks	Add section for fields 2000-2999 vehicle telemetry data and field 2000 for vehicle
		current location.
2015-10-21	Andy Marks	Add new message type APX-LOC for sending of vehicle current location data in
		bulk format
2016-01-05	Andy Marks	Add request for driver's location and associated response examples
2016-01-05	Andy Marks	Increase 1101 Member Name to 60 characters
2016-02-03	Andy Marks	Update examples of RAU message to include optional fields
2016-03-16	Andy Marks	Update 1227, 1228 fields, can be sent both ways
2016-04-07	Andy Marks	Change 1008 to ETA only, Remove fields 1103 (Make/Model) and 1214 (Nat. Grid
2016 06 00	Andri Marilia	Coordinates)  Add field 1116 symptom code field and associated list of industry standard
2016-06-08	Andy Marks	Add field 1116 symptom code field and associated list of industry standard symptom codes
2016-06-08	Andy Marks	Add list of industry standard secondary fault codes and associated field detail in 1205
2016-07-05	Andy Marks	Alter 1014 call received time to date / time
2016-07-05	Andy Marks	Added field 1025 for VCRF email addresses

Clarify ROA 1215 field and add to example job message		T	1	
2016-08-03   Andy Marks   Add 1026 job distance travelled filed	2016-07-07	Andy Marks		Clarify ROA 1215 field and add to example job message
2016-08-15   Andy Marks   Add 1026 job distance travelled field	2016-07-28	Andy Marks		
2016-09-09   Andy Marks   Added 1027 ETA Date Time field	2016-08-03	Andy Marks		Correct 1020 examples to 2 digit year from 4 digit
Added 1027 FTA Date Time field	2016-08-15	Andy Marks		Add 1026 job distance travelled field
2016-09-20   Andy Marks   Added 1028 Technician Notified Date Time field	2016-09-09	Andy Marks		Updated 1203 Passengers field
2016-09-20   Andy Marks   Added 1029 Technician Accepted Date Time field	2016-09-20	Andy Marks		Added 1027 ETA Date Time field
2016-09-20Andy MarksAdded 1030 On Route Date Time field2016-09-20Andy MarksAdded 1031 Clear Date Time field2016-09-20Andy MarksAdded 1032 Complete Date Time field2016-09-20Andy MarksUpdated examples with new Date Time fields 1027-10322016-09-20Andy MarksUpdate 1007 field description to "Job Time"2016-10-05Andy MarksUpdate 1007 field description to "Job Time"2016-12-05Andy MarksUpdate fields definitions for 1227, 1228 as they had commas between the dates when they shouldn't have2017-01-18Andy MarksAdd the job status points definitions section2017-01-25Andy Marks3.4Add N505 outcome code2017-01-25Andy Marks3.4Add 1117 VIN field2017-01-25Andy Marks3.4Add 1033 estimated time of completion (ETC) field2017-01-25Andy Marks3.4Change 1016 ETA supporting text field to also be used for ETC (estimated time of completion) supporting text2017-01-25Andy Marks3.4Add 'PAR' to the list of items when performing a request for authorisation2017-01-25Andy Marks3.4Add 'PAR' to the list of items when performing a request for authorisation nothing once the document has been changed2017-01-30Andy Marks3.4Add the 'Note to Developers' paragraph at the beginning of the document2017-03-16Andy Marks3.6Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns2017-03-24Andy Marks3.7Add binary data transmission messages	2016-09-20	Andy Marks		Added 1028 Technician Notified Date Time field
Added 1031 Clear Date Time field	2016-09-20	Andy Marks		Added 1029 Technician Accepted Date Time field
2016-09-20Andy MarksAdded 1032 Complete Date Time field2016-09-20Andy MarksUpdated examples with new Date Time fields 1027-10322016-09-20Andy MarksUpdate 1007 field description to "Job Time"2016-10-05Andy MarksUpdate name of 1020 field to "ATA Date Time"2016-12-05Andy MarksUpdate fields definitions for 1227, 1228 as they had commas between the dates when they shouldn't have2017-01-18Andy MarksAdd the job status points definitions section2017-01-25Andy Marks3.4Add NS05 outcome code2017-01-25Andy Marks3.4Add 1117 VIN field2017-01-25Andy Marks3.4Add 1033 estimated time of completion (ETC) field2017-01-25Andy Marks3.4Add 1034 estimated time of completion (ETC) field2017-01-25Andy Marks3.4Add "PAR" to the list of items when performing a request for authorisation2017-01-25Andy Marks3.4Add "PAR" to the list of items when performing a request for authorisation on thing once the document has been changed2017-01-30Andy Marks3.4Add the 'Note to Developers' paragraph at the beginning of the document2017-03-16Andy Marks3.5Updated the 100 field to 120 chars to match what's being sent currently2017-03-16Andy Marks3.6Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description2017-08-24Andy Marks3.7Add binary data transmission messages and fields2017-08-24Andy Marks3.8Add leading zero to refusa	2016-09-20	Andy Marks		Added 1030 On Route Date Time field
2016-09-20Andy MarksUpdated examples with new Date Time fields 1027-10322016-09-20Andy MarksUpdate 1007 field description to "Job Time"2016-10-05Andy MarksUpdate name of 1020 field to "ATA Date Time"2016-12-05Andy MarksUpdate fields definitions for 1227, 1228 as they had commas between the dates when they shouldn't have2017-01-18Andy MarksAdd the job status points definitions section2017-01-25Andy Marks3.42017-01-25Andy Marks3.42017-01-26Andy Marks3.42017-01-30Andy Marks3.42017-01-30Andy Marks3.52017-03-16Andy Marks3.52017-03-16Andy Marks3.62017-03-27Andy Marks3.72017-08-24Andy Marks3.72017-08-24Andy Marks3.82017-08-24Andy Marks3.82018-05-04Andy Marks3.82018-05-04Andy Marks3.82018-05-04Andy Marks3.8 </td <td>2016-09-20</td> <td>Andy Marks</td> <td></td> <td>Added 1031 Clear Date Time field</td>	2016-09-20	Andy Marks		Added 1031 Clear Date Time field
2016-09-20Andy MarksUpdate 1007 field description to "Job Time"2016-10-05Andy MarksUpdate name of 1020 field to "ATA Date Time"2016-10-05Andy MarksUpdate fields definitions for 1227, 1228 as they had commas between the dates when they shouldn't have2017-01-18Andy MarksAdd the job status points definitions section2017-01-25Andy Marks3.4Add 1117 VIN field2017-01-25Andy Marks3.4Add 1117 VIN field2017-01-25Andy Marks3.4Add 1033 estimated time of completion (ETC) field2017-01-25Andy Marks3.4Change 1016 ETA supporting text field to also be used for ETC (estimated time of completion) supporting text2017-01-25Andy Marks3.4Add 'PAR' to the list of items when performing a request for authorisation2017-01-25Andy Marks3.4Add 'PAR' to the list of items when performing a request for authorisation2017-01-25Andy Marks3.4Add the 'Note to Developers' paragraph at the beginning of the document2017-03-0Andy Marks3.4Add the 'Note to Developers' paragraph at the beginning of the document2017-03-16Andy Marks3.6Updated the 100 field to 120 chars to match what's being sent currently2017-03-16Andy Marks3.6Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns2017-08-24Andy Marks3.7Add binary data transmission messages and fields2017-08-24Andy Marks3.8Correct TERM-MESS examples2018-07-19Andy	2016-09-20	Andy Marks		Added 1032 Complete Date Time field
2016-10-05   Andy Marks   Update name of 1020 field to "ATA Date Time"	2016-09-20	Andy Marks		Updated examples with new Date Time fields 1027-1032
Update fields definitions for 1227, 1228 as they had commas between the dates when they shouldn't have	2016-09-20	Andy Marks		Update 1007 field description to "Job Time"
when they shouldn't have  2017-01-18 Andy Marks Add the job status points definitions section  2017-01-25 Andy Marks 3.4 Add NSO5 outcome code  2017-01-25 Andy Marks 3.4 Add 1117 VIN field  2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field  2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field  2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field  2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation  2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed  2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document  2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently  2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-07-19 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2016-10-05	Andy Marks		Update name of 1020 field to "ATA Date Time"
2017-01-18 Andy Marks 3.4 Add the job status points definitions section 2017-01-25 Andy Marks 3.4 Add NSOS outcome code 2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field 2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field 2017-01-25 Andy Marks 3.4 Change 1016 ETA supporting text field to also be used for ETC (estimated time of completion) supporting text 2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation 2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed 2017-03-09 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document 2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently 2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description 2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields 2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples 2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples 2018-05-04 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.) 2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes 2019-07-07 Chris White 4.2 Add TOW14 Outcome definition 2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2016-12-05	Andy Marks		Update fields definitions for 1227, 1228 as they had commas between the dates
2017-01-25 Andy Marks 3.4 Add NS05 outcome code 2017-01-25 Andy Marks 3.4 Add 1117 VIN field 2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field 2017-01-25 Andy Marks 3.4 Change 1016 ETA supporting text field to also be used for ETC (estimated time of completion) supporting text field to also be used for ETC (estimated time of completion) supporting text 2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation 2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation 2017-01-25 Andy Marks 3.4 Add the 'Rank' to the list of items when performing a request for authorisation 2017-01-26 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document 2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently 2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description 2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns 2017-03-24 Andy Marks 3.7 Add binary data transmission messages and fields 2017-08-24 Andy Marks 3.8 Replace 11nn with correct field codes in data examples 2018-05-04 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.) 2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes 2019-07-20 Chris White 4.2 Add TOW14 Outcome definition 2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example				when they shouldn't have
2017-01-25 Andy Marks 3.4 Add 1117 VIN field 2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field 2017-01-25 Andy Marks 3.4 Change 1016 ETA supporting text field to also be used for ETC (estimated time of completion) supporting text field to also be used for ETC (estimated time of completion) supporting text 2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation 2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed 2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document 2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently 2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description 2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns 2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields 2017-08-24 Andy Marks 3.X Add leading zero to refusal code table 2017-08-24 Andy Marks 3.8 Correct TERM-MESS examples 2018-05-04 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.) 2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes 2019-07-20 Chris White 4.2 Add TOW14 Outcome definition 2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-01-18	Andy Marks		Add the job status points definitions section
2017-01-25 Andy Marks 3.4 Add 1033 estimated time of completion (ETC) field 2017-01-25 Andy Marks 3.4 Change 1016 ETA supporting text field to also be used for ETC (estimated time of completion) supporting text 2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation 2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed 2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document 2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently 2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description 2017-07-27 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns 2017-08-24 Andy Marks 3.X Add leading zero to refusal code table 2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples 2018-05-04 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.) 2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes 2019-07-20 Chris White 4.2 Add TOW14 Outcome definition 2019-07-08 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-01-25	Andy Marks	3.4	Add NS05 outcome code
2017-01-25 Andy Marks 3.4 Change 1016 ETA supporting text field to also be used for ETC (estimated time of completion) supporting text  2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation  2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed  2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document  2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently  2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description  2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-01-25	Andy Marks	3.4	Add 1117 VIN field
completion) supporting text  2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation  2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed  2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document  2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently  2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description  2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Add leading zero to refusal code table  2017-08-24 Andy Marks 3.8 Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-01-25	Andy Marks	3.4	Add 1033 estimated time of completion (ETC) field
2017-01-25 Andy Marks 3.4 Add 'PAR' to the list of items when performing a request for authorisation 2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed 2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document 2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently 2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description 2017-07-27 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns 2017-08-24 Andy Marks 3.X Add leading zero to refusal code table 2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples 2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples 2018-10-23 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes 2019-07-20 Chris White 4.2 Add TOW14 Outcome definition 2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-01-25	Andy Marks	3.4	Change 1016 ETA supporting text field to also be used for ETC (estimated time of
2017-01-25 Andy Marks 3.4 Change this list to include version number rather than page as the page means nothing once the document has been changed  2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document  2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently  2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description  2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Add leading zero to refusal code table  2017-08-24 Andy Marks 3.8 Correct TERM-MESS examples  2018-05-04 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example				completion) supporting text
nothing once the document has been changed  2017-01-30 Andy Marks 3.4 Add the 'Note to Developers' paragraph at the beginning of the document  2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently  2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description  2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Add leading zero to refusal code table  2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-01-25	Andy Marks	3.4	Add 'PAR' to the list of items when performing a request for authorisation
2017-01-30Andy Marks3.4Add the 'Note to Developers' paragraph at the beginning of the document2017-03-09Andy Marks3.5Updated the 100 field to 120 chars to match what's being sent currently2017-03-16Andy Marks3.6Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description2017-03-16Andy Marks3.6Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns2017-07-27Andy Marks3.7Add binary data transmission messages and fields2017-08-24Andy Marks3.XAdd leading zero to refusal code table2017-08-24Andy Marks3.XReplace 11nn with correct field codes in data examples2018-05-04Andy Marks3.8Correct TERM-MESS examples2018-10-23Andy Marks3.9Add resource index (field # 1034) for job update messages (On route / at scene etc.)2019-07-19Andy Marks4.1Change COOLING to DRIVEBELT in Symptom codes2019-07-20Chris White4.2Add TOW14 Outcome definition2019-09-05Andy Marks4.2Correct 1206 to 1260 in ET request / Response example	2017-01-25	Andy Marks	3.4	Change this list to include version number rather than page as the page means
2017-03-09 Andy Marks 3.5 Updated the 100 field to 120 chars to match what's being sent currently 2017-03-16 Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description 2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns 2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields 2017-08-24 Andy Marks 3.X Add leading zero to refusal code table 2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples 2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples 2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.) 2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes 2019-07-20 Chris White 4.2 Add TOW14 Outcome definition 2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example				nothing once the document has been changed
Andy Marks 3.6 Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC field description  2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Add leading zero to refusal code table  2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-01-30	Andy Marks	3.4	Add the 'Note to Developers' paragraph at the beginning of the document
field description  2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Add leading zero to refusal code table  2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-03-09	Andy Marks	3.5	Updated the 100 field to 120 chars to match what's being sent currently
2017-03-16 Andy Marks 3.6 Clarify the message format in terms of new lines and the use of caret symbols in place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Add leading zero to refusal code table  2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-03-16	Andy Marks	3.6	Add the request for ETC process flow, add ETC to request types. Clarify 1033 ETC
place of carriage returns  2017-07-27 Andy Marks 3.7 Add binary data transmission messages and fields  2017-08-24 Andy Marks 3.X Add leading zero to refusal code table  2017-08-24 Andy Marks 3.X Replace 11nn with correct field codes in data examples  2018-05-04 Andy Marks 3.8 Correct TERM-MESS examples  2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example				field description
2017-07-27Andy Marks3.7Add binary data transmission messages and fields2017-08-24Andy Marks3.XAdd leading zero to refusal code table2017-08-24Andy Marks3.XReplace 11nn with correct field codes in data examples2018-05-04Andy Marks3.8Correct TERM-MESS examples2018-10-23Andy Marks3.9Add resource index (field # 1034) for job update messages (On route / at scene etc.)2019-07-19Andy Marks4.1Change COOLING to DRIVEBELT in Symptom codes2019-07-20Chris White4.2Add TOW14 Outcome definition2019-09-05Andy Marks4.2Correct 1206 to 1260 in ET request / Response example	2017-03-16	Andy Marks	3.6	Clarify the message format in terms of new lines and the use of caret symbols in
2017-08-24Andy Marks3.XAdd leading zero to refusal code table2017-08-24Andy Marks3.XReplace 11nn with correct field codes in data examples2018-05-04Andy Marks3.8Correct TERM-MESS examples2018-10-23Andy Marks3.9Add resource index (field # 1034) for job update messages (On route / at scene etc.)2019-07-19Andy Marks4.1Change COOLING to DRIVEBELT in Symptom codes2019-07-20Chris White4.2Add TOW14 Outcome definition2019-09-05Andy Marks4.2Correct 1206 to 1260 in ET request / Response example				· -
2017-08-24Andy Marks3.XReplace 11nn with correct field codes in data examples2018-05-04Andy Marks3.8Correct TERM-MESS examples2018-10-23Andy Marks3.9Add resource index (field # 1034) for job update messages (On route / at scene etc.)2019-07-19Andy Marks4.1Change COOLING to DRIVEBELT in Symptom codes2019-07-20Chris White4.2Add TOW14 Outcome definition2019-09-05Andy Marks4.2Correct 1206 to 1260 in ET request / Response example	2017-07-27	Andy Marks	3.7	Add binary data transmission messages and fields
2018-05-04Andy Marks3.8Correct TERM-MESS examples2018-10-23Andy Marks3.9Add resource index (field # 1034) for job update messages (On route / at scene etc.)2019-07-19Andy Marks4.1Change COOLING to DRIVEBELT in Symptom codes2019-07-20Chris White4.2Add TOW14 Outcome definition2019-09-05Andy Marks4.2Correct 1206 to 1260 in ET request / Response example	2017-08-24	Andy Marks	3.X	Add leading zero to refusal code table
2018-10-23 Andy Marks 3.9 Add resource index (field # 1034) for job update messages (On route / at scene etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2017-08-24	Andy Marks	3.X	Replace 11nn with correct field codes in data examples
etc.)  2019-07-19 Andy Marks 4.1 Change COOLING to DRIVEBELT in Symptom codes  2019-07-20 Chris White 4.2 Add TOW14 Outcome definition  2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2018-05-04	Andy Marks	3.8	Correct TERM-MESS examples
2019-07-19Andy Marks4.1Change COOLING to DRIVEBELT in Symptom codes2019-07-20Chris White4.2Add TOW14 Outcome definition2019-09-05Andy Marks4.2Correct 1206 to 1260 in ET request / Response example	2018-10-23	Andy Marks	3.9	Add resource index (field # 1034) for job update messages (On route / at scene
2019-07-20Chris White4.2Add TOW14 Outcome definition2019-09-05Andy Marks4.2Correct 1206 to 1260 in ET request / Response example				'
2019-09-05 Andy Marks 4.2 Correct 1206 to 1260 in ET request / Response example	2019-07-19	Andy Marks	4.1	Change COOLING to DRIVEBELT in Symptom codes
	2019-07-20	Chris White	4.2	Add TOW14 Outcome definition
2020-06-03 Andy Marks 4.3 Add 1120 fuel type field and associated table of approved fuel types	2019-09-05	Andy Marks	4.2	
	2020-06-03	Andy Marks	4.3	Add 1120 fuel type field and associated table of approved fuel types

#### Introduction

Jobs (Vehicle breakdown incidents) are traditionally passed from the clubs to the vehicle recovery operators electronically using the ANS network in a format described in the ANS data transmission standard document. It is also possible for a vehicle recovery operator to send a job to another for example when subcontracting a job. For the purposes of this document we will use the terms JO (Job Originator, meaning the organization that sent the job) and JR (Job Recipient, meaning the organization that received the job).

Each JO or JR has a connection to the ANS network and is identified via a unique 7-digit numeric code known as an ANS node ID. Some JO's and JR's have multiple ANS node IDs to allow their systems to split out jobs to different part of their organization.

#### **Message Format**

Connection to the ANS network is usually via the AutoConnect Client, a software application provided by Apex Networks. The ANS data transmission format is text file based, with the AutoConnect client simply reading text files

on the local machine then sending them to their destination where the files are reconstituted by another AutoConnect client at the other end. It is up to the JO or JR system to read and write the files, although Apex do provide a managed code interface that can read and write the files in the correct format. Each message sent over ANS must specify a source and destination ANS node ID and the message contents. The message contents consist of a number of fields identified by a 4-digit numeric code.

#### An example message is:

```
SOURCE=2000001
DEST=2000002
MESSAGE=
"9100,TERM-MESS"
"1220,This is a terminal message type message"
"9999 2"
```

#### Please note that this message can also be represented as:

```
SOURCE=2000001
DEST=2000002
MESSAGE="9100,TERM-MESS""1220,This is a terminal message type message""9999,2"
```

- The standard is not designed to be read line by line; the fields are individually identified as being enclosed in
  quotation marks. Carriage returns in the fields are to be represented by caret symbols (^) and to be
  converted by the recipient system.
- The source and destination fields identify the ANS node ID that this message comes from and is going to.
   Note that it is not actually mandatory to have a source if the ANS connection only has a single node but it is better to include it regardless.
- The first field in the message (9100) is the message type and is mandatory. A list of message types can be found in the standards document.
- The last field in the message (9999) denotes the number of preceding fields in the message.
- All text is encoded is UTF-8 format.
- Records should be encapsulated in double quotes (&H22).
- End of lines can be represented as CR-LF (&H13 &H10) or as just LF (&H10).
- There is no limitation to the size of message transmitted by either Work Provider or Work Recipient, however jobs may be split into multiple messages (the first being an JOB type and subsequent ones UPD type) for historical reasons although this use is discouraged.

#### **Message Acknowledgements**

Each job-related message sent across ANS will result in an ACK message being generated by the AutoConnect client at the receiving end, this is a very low-level acknowledgment that the message has been received at the other end (but not that it has been processed). The ACK is in the following format:

```
SOURCE=2000001

DEST=2000002

MESSAGE=

"9100,MTS-ACK"

"1004,<Unique Job Number>"

"9999,2"
```

#### **Example Messages**

Please note that these message examples do not contain all permutation of fields that can be sent, please consult the rest of the document for these.

#### Initial Job Dispatch (JO - JR)

```
"9100, IPA-JOB"
"1004, IPA0412668338-1"
"1005, 13/11/12"
"1007, 10:08"
"1014, 13/11/12, 10:03"
"1201, 037 9480337"
"1205, GF23, GEAR BOX PROBLEMS"
```

```
"1118, FORD"
"1119, MONDEO"
"1106, STEERING HEAVY, Steering heavy - power steering not working"
"1108, Diesel 1900cc",
"1120, DIESEL"
"1107, Manual"
"1200, AT MCCORMACKS PETROL STATION ON MAILCOACH ROAD IN SLIGO"
"1105, 0950363"
"1215, 10"
"1112, N"
"1203, 1, 0"
"0019, 62.00"
"0020, 5240033"
"1285, application/pdf, Terms of business, <base 64 data>"
"9999, 21"
```

#### Request for Revised ETA (JO - JR)

```
"9100, IPA-REQ"
"1004, IPA0413856987-1"
"1260, ETA"
"9999, 3"
```

#### Revised ETA Response (JR – JO)

```
"9100,APX-RSP"
"1004,2213543856987-1"
"1008,10:28"
"1027,19/09/16,10:28"
"1016,Comments for revised ETA"
"9999,5"
```

# Request for Revised ETC (JO - JR)

```
"9100, IPA-REQ"
"1004, IPA0413856987-1"
"1260, ETC"
"9999, 3"
```

#### Revised ETC Response (JR - JO)

```
"9100,APX-RSP"
"1004,2213543856987-1"
"1008,10:28"
"1033,19/09/16,10:28"
"1016,Comments for revised ETC"
"9999,5"
```

#### Request for ATA (JO - JR)

```
"9100,AA-REQ"
"1004,2213543856987-1"
"1260,ATA"
"9999,3"
```

#### ATA Message (JR - JO)

```
"9100,MTS-RSP"
"1004,IPA0413856987-1"
"1020,13/08/14,15:35"
"9999,3"
```

#### Acceptance of Job (JR - JO)

```
"9100,MTS-ETA"
"1004,GX34567"
"1005,13/11/12"
"1007,10:07"
"1012,55"
"1008,11:02"
"1027,13/11/12,11:02"
"1001,T016"
```

```
"9999,8"
```

#### Refusal of Job (JR - JO)

```
"9100,MTS-REF"
"1004,GP02920 06FE93551034"
"1005,13/11/12"
"1007,10:12"
"9101,02"
"9999,5"
```

#### Cancellation of Job (JO - JR)

```
"9100, CANCEL"
"1001, 90045C"
"1004, G615833"
"9999, 3"
```

# Job rebooked (JR - JO)

```
"9100,MTS-RBK"
"1004,IPA0413856987-1"
"1001,109265"
"1227,21/03/13 14:02"
"1228,21/03/13 14:32"
"1231,GT"
"9999,6"
```

#### Technician Notified Update (JR - JO)

```
"9100,MTS-UPD"
"1004,2U4350-2631940"
"1021,10:46"
"1028,19/09/16,10:46"
"9999,4"
```

#### Technician Accepted Update (JR – JO)

```
"9100,MTS-UPD"
"1004,2U4350-2631940"
"1022,10:56"
"1029,19/09/16,10:56"
"9999,4"
```

#### On Route Update (JR - JO)

```
"9100,MTS-UPD"
"1001,3047935"
"1004,2U4350-2631940"
"1005,13/11/12"
"1007,10:12"
"1018,10:46"
"1030,13/11/16,10:46"
"1209,Andy Marks"
"1211,GL08VCK"
"1023,53.236534545,-1.234234234,13/11/2012 10:46" << OPTIONAL LOCATION OF DRIVER "9999,10"
```

#### On Scene Update (JR - JO)

```
"9100,MTS-UPD"
"1001,3047935"
"1004,2U4350-2631940"
"1010,13"
"1020,13/11/12,10:46"
"1023,53.236534545,-1.234234234,13/11/2012 10:46" << OPTIONAL LOCATION OF DRIVER
"9999,6"
```

### Request for authorisation (JR - JO)

```
"9100,MTS-RAU"
"1004,IPA0413856987-1"
"1001,109265"
```

```
"1252,MLG, 63"
"1252,SKA,1"
"1212,Vehicle in awkward position in underground garage"
"1205,COO003,Coolant,26,Fluid Level Low"
"1208,Haverhill Road Romford RM15"
"1221,52.125632434,-1.356555656"
"9999,9"
```

This is sent by an operator requesting a total mileage of 63 miles (any inclusive miles can be deducted by club system) and a single set of skates. The text to support the request for these items is included. The response from the club is expected to be an updated job with appropriate authorisation, but no new fields are required for that. The message may also contain the job destination in text and GPS coordinates in case the destination has changed and that is the reason for the request.

#### Job Clear-down (JR - JO)

```
"9100, MTS-CLR"
"1001, 102965"
"1004,2U4350-2631940"
"1005,13/11/12"
"1007,10:12"
"1008,10:46"
"1027,13/11/12,10:46"
"1010,13"
"1011,25"
"1020,13/11/12,12:46"
"1009,10:58"
"1031,13/12/16,10:58"
"1032,13/12/16,11:35"
"1011,33"
"1106,83243"
"1019,4"
"1217, GARAGE, Customer with car at garage"
"1205, COO003, Coolant, 26, Fluid Level Low"
"1207, TOW03, Tow to home address"
"9999,19"
```

```
Job Invoice (JR – JO)
"9100,MTS-INV"
"0000,60-48451"
"0001,20.00,31.00"
"0010,0.00,8.00,CLAIM HANDLING FEE"
"0013,39.00"
"0014,6.20"
"0015,45.20"
"1000,GB71262575"
"1001,104369"
"1003,13/11/12"
"1004,XX37689"
"1005,13/11/12"
"1007,13:55"
"1008,14:54"
"1027,13/11/12,14:54"
"1009,14:42"
"1031,13/11/12,14:42"
"1010,21"
"1020,13/11/12,12:46"
"1032,13/12/16,11:56"
"1217, GARAGE, CUSTOMER WITH CAR AT GARAGE"
"1011,47"
"1105,FL01WZC"
"1205,GF24 - BATTERY FAULTY
                                       NON STARTER-NON STARTER - DOK"
"1207,FIX02
                                      REPAIRED ON SCENE"
"9999,25"
```

#### Vehicle Location Data (JR - \*)

```
"9100,APX-LOC"
"2000,GK65HFA,Andy Marks,51.2234234,-1.22334234,21/10/2015 10:23,ABC12345" ← Repeated for each vehicle.
"9999,2"
```

#### Request for Drivers Location (JO - JR)

```
"9100,XXX-REQ"
"1004,<JOB NUMBER HERE>"
"1260,LAT"
"9999,3"
```

#### Response to Drivers Location Request (JR- JO)

```
"9100,XXX-RSP"
"1004,<JOB NUMBER HERE>"
"1023,53.236534545,-1.234234234,13/11/2012 10:46"
"9999,3"
```

Note that it is possible to get no response to a request of type LAT, as there may be no driver location data available or the driver may not be on route yet.

#### Request for the next job image (JO - JR)

```
"9100,XXX-REQ"
"1004,<JOB NUMBER HERE>"
"1260,IMG"
"9999,3"
```

#### Response to Image Request (JR-JO)

```
"9100,APX-RSP"
"1004,JOB NUMBER HERE"
"1019,6" ← The number of available images left for transmission.
"1285,image/jpeg,<File Description>,<BASE 64 ENCODED IMAGE>"
"9999,4"
```

The job recipient's system should always reply with a response to this request, if the job recipient's system does not support or allow the request then 0 should be returned as the number of available images remaining. It is up to the job recipient's system to keep track of the images already sent, responding with the next available unsent image or zero if no more available.

#### **Message Fields**

# Fields 0000 - 1000: Charge related data

Record No		Status	Repetitions	Name
0000		Active	1 (Max)	Invoice Number
Format	Direction	Usage		
AAAAAAAAAAA	To club	Mandatory	for XXX-INV mes	ssage
Remarks				
Unique Invoice numb	er			
Examples				
"0000,A74285/BRIT1	"			
"0000,A74284/REDS	TR"			
"0000,B85140/BRITA	NNI"			
"0000,A66763/GESA"	,			
"0000,00-81149"				

Record No		Status	Repetitions	Name
0001		Active	2 (Max)	Call out Charge
Format	Direction	Usage		
DD.DD,DDDD.DD	To club	Mandatory f	or XXX-INV messa	ge
Remarks				
VAT Rate followed	by Net Value. N	Aultiple lines ca	an be used to repr	esent 0% VAT rate for insurance purposes
Examples				
"0001,20.00, 31.0	0"			

Record No		Status	Repetitions	Name
0002		Active	5 (Max)	Mileage Charge
Format	Direction	Usage		
DD.DD,DDDD.DD,DDDD.DD	To club	Optional		
Remarks				
VAT Rate followed by Number of miles	, Rate per mile	, Net Value. T	he number of mil	es is actual mileage and doesn't take into account any
free miles.				
	TotalMileag	e - (TotalChai	rge / MileageRate)	) = FreeMiles
Sc	to calculate th	e number of	free miles in the fo	ollowing example:
		20.00,10	00,0.65,52.00	
	Fre	ee Miles = 100	0 - (52.00 / 0.65) =	: 20
Examples				
"0002 20 00 1 00 0 96 0 96"				

Record No		Status	Repetitions	Name				
0003		Active	1 (Max)	Labour				
Format	Direction	Usage						
DD.DD	To club	Optional						
Remarks								
VAT Rate follo	VAT Rate followed by Number of hours, Rate per hour, Net Value							
Examples								
"0003,20.00,	0.50, 38.00, 19	.00"						

Record No		Status	Repetitions	Name
0004		Active	1 (Max)	Toll Charge
Format	Direction	Usage		
DD.DD,DDDD.DD	To club	Optional		
Remarks				
VAT Rate followed by I	Net Value.			
Examples				
"0004,20.00, 5.00"				

Record No		Chatus	Donatitions	Nama				
		Status	Repetitions	Name				
0005		Active	1 (Max)	Hours				
Format	Direction	Usage						
DD.DD,DDDD.DD	To club	Optional						
Remarks								
VAT Rate followed	by Number of ho	ours, Rate per ho	ur, Net Value. The	number of hours is actual time and doesn't take into account any free				
hours.								
	TotalHours - (TotalCharge / HourlyRate) = FreeHours							
		So to calculate	the number of fre	e hours in the following example:				
			20.00,100,	0.65,52.00				
		F	ree Hours = 100 -	(52.00 / 0.65) = 20				
Examples								
"0005,20.00, 4.75,	, 55.00, 261.25"							

Record No		Status	Repetitions	Name
0006		Unused	1 (Max)	Extra Man
Format	Direction	Usage		
DD.DD,DDDD.DD	To club	Optional		
Remarks				
VAT Rate followed k	y Number of ho	urs, Rate per ho	our, Net Value	
Examples				
"0006,20.00, 1.00,	18.04, 18.04"			

Record No		Status	Repetitions	Name	
0007		Unused	1 (Max)	Service Van	
Format	Direction	Usage			
DD.DD,DDDD.DD	To club	Optional			
Remarks					
VAT Rate followed by Number of hours, Rate per hour, Net Value					

Examples

0007,20.00, 2.00, 38.00, 76.000013, 440.50"

Record No		Status	Repetitions	Name	
0008		Active	1 (Max)	Parts Sold	
Format	Direction	Usage			
DD.DD,DDDD.DD	To club	Optional			
Remarks					
VAT Rate followed b	y Net Value and	Description of p	part		
Examples					
XXX					

Record No		Status	Repetitions	Name
0009		Unused	1 (Max)	Fuel Supplied
Format	Direction	Usage		
DD.DD,DDDD.DD	To club	Optional		
Remarks				
VAT Rate followed	by Net Value			
Examples				
XXX				

Record No		Status	Repetitions	Name		
0010		Active	1 (Max)	Other Charges		
Format	Direction	Usage		-		
DD.DD,DDDD.DD,A*22	To club	Optional				
Remarks						
VAT Rate followed by Net Value and Description of the charge						
Examples						
0010, 0.00, 8.00, CLAIM	HANDLING FEE					

0011		Unused	1 (Max)	Trailer Miles
Format	Direction	Usage		
DD.DD,DDDD,DD.DD,DDDD.DD	To club	Optional		
Remarks				
VAT Rate followed by number of	miles, rate per	mile and Net v	/alue	
Examples				
XXX				

Record No		Status	Repetitions	Name
0012		Active	1 (Max)	Quoted Price
Format	Direction	Usage		
DD.DD,DDDD.DD	Op > Op	Optional		
Remarks				
VAT Rate followed I	by Net Value			
Examples				
XXX				

Record No		Status	Repetitions	Name
0013		Active	1 (Max)	Invoice Sub Total
Format	Direction	Usage		
DDDD.DD	To club	Optional		
Remarks				
Invoice Sub To	otal in Pounds			
Examples				
0013, 39.00				

Record No		Status	Repetitions	Name	
0014		Active	1 (Max)	VAT Amount	
Format	Direction	Usage			
DDDD.DD	To club	Optional			
Remarks					
Invoice VAT A	Invoice VAT Amount in Pounds				

**Examples** 0014, 9.34

Record No		Status	Repetitions	Name
0015		Active	1 (Max)	Invoice Total
Format	Direction	Usage		
DDDD.DD	To club	Optional		
Remarks				
Total Invoice	Amount in Pounds			
Examples				
0015, 48.00				

0017		Unused	1 (Max)	Account Reference
Format	Direction	Usage		
A*8	To club	Optional		
Remarks				
Account refer	ence Identifier			
Examples				
XXX				

Record No		Status	Repetitions	Name	
0018		Active	1 (Max)	Authorised Miles	
Format	Direction	Usage			
DDDD.DD	From club	Optional			
Remarks					
Mileage autho	Mileage authorised for this job.				
Examples					
0018,153					

Record No		Status	Repetitions	Name	
0019		Active	1 (Max)	Authorised Cost	
Format	Direction	Usage			
DDDD.DD	From club	Optional			
Remarks					
Authorised co	Authorised cost of the job ex VAT				
Examples					
0019,53.26					

Record No		Status	Repetitions	Name	
0020		Active	1 (Max)	Authorisation Number	
Format	Direction	Usage			
D*20	From club	Optional			
Remarks					
Authorisation	code used to supp	ort records 0018	or 0019		
Examples					
0020,5215355	0020,5215355				

# Fields 1000 – 1100: Job Recipient Details

Record No		Status	Repetitions	Name		
1000		Active	1 (Max)	VAT Number		
Format	Direction	Usage				
A*11	To club	Optional				
Remarks	Remarks					
Used for ager	nt to specify his VA	T number for bill	ing.			
Examples	Examples					
1000,GB1036	1000,GB103605264					

Record No		Status	Repetitions	Name	
1001		Active	1 (Max)	Agent Number	
Format	Direction	Usage			
A*7	From club	Optional			

Remarks				
Motoring Organisation Agent reference				
Examples				
1001,REC002233/0000				
1001,A26OB				

1002		Unused	1 (Max)	Accepted by	
Format	Direction	Usage			
A*2	From club	Optional			
Remarks					
Initials of job operator					
Examples					
XXX					

<b>Record No</b>		Status	Repetitions	Name		
1003		Active	1 (Max)	Invoice Date		
Format	Direction	Usage				
A*10	To club	Optional				
Remarks	Remarks					
DD/MM/YY d	ate of invoice					
Examples						
1003,09/11/1	1003,09/11/12					

Record No		Status	Repetitions	Name			
1004		Active	1 (Max)	Job No			
Format	Direction	Usage					
A*20	From club	Mandatory	Mandatory for all job-related messages				
Remarks	·						
Generated by	y the Work provide	and must inclu	ude their identifier a	s a prefix.			
Examples							
1004,DCU/18	3913932						
1004,HSB/18917856							
1004,ERSJ01499306							
1004,CMC1492270CR#557							

Record No		Status	Repetitions	Name		
1005		Active	1 (Max)	Job Date		
Format	Direction	Usage				
A*10	From club	Mandatory for all job-related messages				
Remarks						
DD/MM/YY : a	assumed to be san	ne as date of call				
Examples	Examples					
1005,23/10/1	2					

Record No		Status	Repetitions	Name
1006		Active	1 (Max)	Case Number
Format	Direction	Usage		
A*19	From club	Optional		
Remarks				
Case number,	therefore can be r	elated to multip	le jobs or reference:	S.
Examples				
1006,M09876	5			
1006,B46938				
1006,1165524	48			

Record No		Status	Repetitions	Name		
1007		Active	1 (Max)	Job Time		
Format	Direction	Usage				
A*5	From club	Mandatory				
Remarks						
The time the jo	The time the job was sent to the operator					
Examples	Examples					

1007,10:47

Record No Status Repetitions Name

Record No		Status	Repetitions	Name	
1008		<mark>Active</mark>	1 (Max)	ETA	
Format	Direction	Usage			
HH:MM	To club	Mandatory			
Remarks					
Represents th	ne estimated time	of arrival in a job accepta	nce or an update message		
Examples					
1008,12:01					
1008,16:22					

<b>Record No</b>		Status	Repetitions	Name	
1009		Active	1 (Max)	Clear Time	
Format	Direction	Usage			
A*5	To club	Optional			
Remarks					
HH:MM Actua	al Time				
Examples					
1009,20:55					

Record No		Status	Repetitions	Name	
1010		Active	1 (Max)	On Scene Time Elapsed	
Format	Direction	Usage			
A*4	To club	Optional			
Remarks					
Elapsed time i	n minutes from ti	me of call (1007 r	ecord)		
Examples					
1010,46					

Record No		Status	Repetitions	Name	
1011		Active	1 (Max)	Clear Time Elapsed	
Format	Direction	Usage			
A*4	To club	Optional			
Remarks					
Elapsed time	in minutes from Jo	bb Time (1007 red	ord)		
Examples					
1011,153					

Record No		Status	Repetitions	Name		
1012		Active	1 (Max)	ETA		
Format	Direction	Usage				
A*4	To club	Mandatory				
Remarks						
Estimated Tin	ne of Arrival. Elaps	ed time in minute	s from Job Time (1	.007 record)		
Examples						
1012,61						

<b>Record No</b>		Status	Repetitions	Name
1013		Active	1 (Max)	???
Format	Direction	Usage		
A*4	To club	Mandatory		
Remarks				
Examples				
1013,2053250	2/1			
1013,064/28	TEMP NUMBER			

Record No		Status	Repetitions	Name
1014		Active	1 (Max)	Call Received Time
Format	Direction	Usage		
DD/MM/YY,HH:MM	From club	Optional		

Remarks	
Date & time the job was taken at source by the job originator	
Examples	
1014,05/07/16,14:53	

1015		Unused	1 (Max)	Call Received Date	
Format	Direction	Usage			
A*10	From club	Optional			
Remarks					
DD/MM/YY					
Examples					
XXX					

Record No		Status	Repetitions	Name
1016		Active	1 (Max)	Supporting Text for Updated ETA and for ETC (estimated time of completion)
Format	Direction	Usage		
A*100	To club	Optional		
Remarks				
Any support	ing text to be sent I	back with an upd	ated ETA or ETC to	the club
Examples				
"1016,Traffic	delays on route"			

Record No		Status	Repetitions	Name
1017		Active	1 (Max)	UTC Time
Format	Direction	Usage		
N/A	From Club	Used internal	ly in MTT software	
Remarks				
Should not be u	sed over ANS, use	ed for sending da	nta to MTT PDAs	
Examples				
"1017,"				
"1017,"				

Record No		Status	Repetitions	Name
1018		Active	1 (Max)	Dispatch Time
Format	Direction	Usage		
A*5	To club	Optional		
Remarks				
HH:MM Act	ual Time			
Examples				
1018,08:02				

Record No		Status	Repetitions	Name
1019		New	1 (Max)	Image Count
Format	Direction	Usage		
N*2	To club	Optional		
Remarks				
The number of	of images taken by	the operator ava	ailable for this job	
Examples				
"1019,0"				
"1019,5"				

Record No		Status	Repetitions	Name
1020		Active	1 (Max)	ATA Date Time – Actual Time of Arrival Date Time
Format	Direction	Usage		
DD/MM/YY,HH:MM	To club	Optional		
Remarks				
Indicates the Actual Tir	ne of Arrival by t	he technician to	the scene of the s	stricken vehicle
Examples				
1020,13/12/12,12:01				
1020,21/09/11,16:22				

Record No		Status	Repetitions	Name
1021		Active	1 (Max)	Technician Notified
Format	Direction	Usage		
HH:MM	To club	Optional		
Remarks				
Time (24 hour clock) at whi	ich Service Provid	er's Technician	was notified of job (i	i.e. when the job was dispatched to the driver)
Examples				
1021,07:30				
1021,18:42				

Record No		Status	Repetitions	Name
1022		Active	1 (Max)	Technician Accepted
Format	Direction	Usage		
HH:MM	To club	Optional		
Remarks				
Time (24 hour clock) at which	ch Service Provide	r's Technician accepte	ed the job	
Examples				
1022,07:30				
1022,18:42				

Record No	Status	Repetitions	Name	
1023		Active	1 (Max)	Technician Last Known Location
Format	Direction	Usage		
DD.DDDDD,DDD.DDDDD,dd/MM/YYYY	To club	Optional		
HH:mm:ss				

#### Remarks

Last known Latitude and Longitude (with timestamp) of the Service Provider's Resource. This is to be added to every message sent to clubs once the technician has set off up to at-scene.

Note that 'Last Known' means the last known in relation to the message being sent. For example if an at-scene message is being sent then the last known location is the one immediately prior to the at-scene time.

#### Examples

1023,55.12345,1.43565,01/05/2014 11:05:12

Record No		Status	Repetitions	Name		
1024		Active	1 (Max)	Images Required		
Format	Direction	Usage				
A*1	From Club	Optional, De	fault is 'N'			
Remarks						
Are images re	equired to be taken	for this job?				
Examples	Examples					
"1024,Y"						
"1024,N"						

Record No		Status	Repetitions	Name			
1025		Active	1 (Max)	VCRF Email Address			
Format	Direction	Usage					
A*400	From Club	Optional					
Remarks							
Semi-colon d	elimited list of ema	il addresses to s	end any Vehicle Cor	ndition Report Forms to once complete			
Examples	Examples						
"1025,amark	s@apex-networks.	com"					
"1025,amark	s@apex-networks.	com;cwhite@ap	ex-networks.com"				

Record No		Status	Repetitions	Name
1026		Active	*	Job Distance Travelled
Format	Direction	Usage		
A*4000	To Club	Optional		
Remarks				

Contains data to identify for a given service (i.e. a vehicle / driver) on a job, the distances travelled for various parts of the service. This field can be repeated any number of times, once for each driver / vehicle and the field contains the following data in a comma separated format:

- Service Index (1 based index of service on the job)
- Contractors Vehicle VRM (stripped of commas)

- On Route Location Latitude
- On Route Location Longitude
- On Route Location Date Time (dd/MM/yy)
- At-Scene Location Latitude
- At-Scene Location Longitude
- At-Scene Location Date Time (dd/MM/yy)
- On Route to At-Scene Distance Miles
- Clear Location Latitude
- Clear Location Longitude
- Clear Location Date Time (dd/MM/yy)
- At Scene to Clear Distance Miles
- Complete Location Latitude
- Complete Location Longitude
- Complete Location Date Time (dd/MM/yy)
- Clear to Complete Distance Miles

Clear means 'cleared scene' and should generally have the same location as the at-scene, complete is when the vehicle being attended is either fixed at the side of the road (in which case will have the same location & time as the clear) or is dropped off after a tow to destination.

#### **Examples**

 $\label{eq:control_co$ 

Record No		Status	Repetitions	Name
1027		Active	1 (Max)	ETA (Estimated Time of Arrival) Date Time
Format	Direction	Usage		
DD/MM/YY,HH:MM	To club	Optional		
Remarks				
Indicates the estimate	d time of arriva	l when accepting	g a job or sending a	nn ETA update to the job originator
This field will eventual	ly replace the ex	kisting 1008/101	2 fields	
Examples				
1027,13/12/12,12:01				
1027 21/09/11 16:22				

Record No		Status	Repetitions	Name		
1028		Active	1 (Max)	Technician Notified Date Time		
Format	Direction	Usage				
DD/MM/YY,HH:MM	To club	Optional				
Remarks						
Indicates the date and	time the job wa	s sent from the	operator's system	to the technician that will do the job		
This field will eventual	ly replace the ex	isting 1021 field	1			
Examples						
1028,13/12/12,12:01						
1028 21/09/11 16:22						

Record No		Status	Repetitions	Name		
1029		Active	1 (Max)	Technician Accepted Date Time		
Format	Direction	Usage				
DD/MM/YY,HH:MM	To club	Optional				
Remarks						
Indicates the date and	time the job w	as accepted by th	ne technician			
This field will eventual	ly replace the e	xisting 1022 field	1			
Examples	Examples					
1029,13/12/12,12:01						
1029,21/09/11,16:22						

Record No		Status	Repetitions	Name	
1030		Active	1 (Max)	On Route Date Time	
Format	Direction	Usage			
DD/MM/YY,HH:MM	To club	Optional			
Remarks					
Indicates the date and	time the job w	as marked as on	route by the techr	nician	
This field will eventually replace the existing 1018 field					
Examples					

1030,13/12/12,12:01 1030,21/09/11,16:22

Record No		Status	Repetitions	Name
1031		Active	1 (Max)	Clear Date Time
Format	Direction	Usage		
DD/MM/YY,HH:MM	To club	Optional		
Remarks				
Indicates the date and	time the job was	marked as clea	ir of scene by the t	technician
This field will eventual	ly replace the exi	sting 1009 / 101	.1 fields	
Examples				
1031,13/12/12,12:01				
1031,21/09/11,16:22				

Record No		Status	Repetitions	Name
1032		Active	1 (Max)	Complete Date Time
Format	Direction	Usage		
DD/MM/YY,HH:MM	To club	Optional		
Remarks				
Indicates the date and	time the job wa	s marked as co	mplete by the tech	nician
Examples				
1032,13/12/12,12:01				
1032,21/09/11,16:22				

Record No		Status	Repetitions	Name		
1033		Active	1 (Max)	ETC (Estimated time of completion)		
Format	Direction	Usage				
DD/MM/YY,HH:MM	To club	Optional				
Remarks						
Indicates the estimated date and time the technician will complete the job by (complete in this case means he leaves the scene if a roadside or delivery if in the case of a tow). This field will be sent in an update message back to the club with optional supporting notes in the 1016 field. An update for ETC can also be requested via a REQ message						
Examples						
1033,13/12/12,12:01						

Record No		Status	Repetitions	Name		
1034		Active	1 (Max)	Resource Index		
Format	Direction	Usage				
N*1	To club	Optional				
Remarks						
Indicates for a job update message going from JR to JO the resource the update message applies to. This caters for scenarios where there are multiple resources on a job and identifies which resource the message relates to. Used in Issued to Driver / Accepted by Driver / On Route / At Scene update messages. It's a 1-based index meaning the first resource is denoted 1, second 2 etc.						

**Examples** 1033,1

1033,21/09/11,16:22

1033,2

# Fields 1100 – 1300: Job Details

Record No		Status	Repetitions	Name
1100		Active	1 (Max)	Membership No / Cover
Format	Direction	Usage		
A*120	From club	Optional		
Remarks				
Membership	Number			
Examples				
1100,117641	.54			
1100,OLJX34	BD02			
1100,STGY14	BD06			

Record No	Status	Repetitions	Name
1101	Active	1 (Max)	Clients Name

Format	Direction	Usage					
A*60	From club	Optional					
Remarks							
Members Na	Members Name – The name of the member						
Examples							
1101,BRITTEN MR R							
1101,GUPTA MR A							

Record No		Status	Repetitions	Name			
1102		Active	5 (Max)	Members Address			
Format	Direction	Usage					
A*50	From club	Optional					
Remarks							
Each line s add	ed to this field up	to three times, c	omma separated.				
Examples	Examples						
1102, MILDENI	1102, MILDENHALL ROAD VEH ON R/S>>>						
1102,143 Farm	1102,143 Farmer's Rd,LONDON,london SE5 0TW						

1103		Unused	1 (Max)	Make and Model			
Format	Direction	Usage	,				
A*15,A*15	From club	Optional					
Remarks							
Describes the	vehicle awaiting t	he attendance of	the work recipier	nt.			
Examples							
1103,TALBOT EXPRESS M/HOME							
1103,VAUXHALL MOVANO 3500 CDT							
1103,FORD FIE	ESTA						

Record No		Status	Repetitions	Name					
1104		Active	1 (Max)	Vehicle Category					
Format	Direction	Usage							
A*9	From club	Optional							
Remarks									
If Vehicle is a	a motorbike, new se	econd field to inc	dicate presence of fa	airings, top-box, and panniers					
Examples									
1104,CAR									
1104,People	carrier								
1104,2WD									
1104,CAR / SMALL VAN									
1104,MOTO	1104,MOTORBIKE, Fairings, Top-box, Panniers								
1104,MOTO	RBIKE, Top-box								

Record No		Status	Repetitions	Name		
1105		Active	1 (Max)	Vehicle Reg No		
Format	Direction	Usage				
A*9	From club	Optional				
Remarks						
No spaces to b	be included					
Examples						
1105,CAN456	1105,CAN456V					

Record No		Status	Repetitions	Name
1106		Active	1 (Max)	Odometer Reading
Format	Direction	Usage		
D*7	From / To club	Optional		
Remarks				
Examples				
1106,70438				

Record No	Status	Repetitions	Name

1107		Active	1 (Max)	Transmission Type			
Format	Direction	Usage					
A*25	From club	Optional					
Remarks							
Examples							
1107, Manual							
1107,AUTON	1107,AUTOMATIC 2WD						
1107,Auto	1107,Auto						
1107,MAN							

Record No		Status	Repetitions	Name
1108		Active	1 (Max)	Engine and Fuel Type
Format	Direction	Usage		
A*25	From/To club	Optional		
Remarks				
THIS FIELD W	ILL BE CHANGED TO	<b>ENGINE DETAI</b>	LS IN DUE COURSE	
Examples				
1108,PET				
1108, 2400 Ui	nleaded			
1108,DSL				
1108,DIESEL				
1108.Petrol 1	600cc			

Record No		Status	Repetitions	Name
1109		Active	1 (Max)	Drivers Location
Format	Direction	Usage		
A*19	From club	Optional		
Remarks				
Location of o	driver . By default 'W	/ith Vehicle'		
Examples				
1109,With V	ehicle en la			
1109,40, Riv	erbourne Road, Sali	sbury, UK, SP1 1	NS	
1109,COA 5r	mins - Underground	c/p -Multi Store	y Car Park, Vastern	Road, Reading, UK, RG1 8BT (Reading station)
1109,halfwa	y along Combs Lane	e, Stowmarket, S	uffolk, UK, IP14 2DI	3

Record No		Status	Repetitions	Name
1110		Active	1 (Max)	Vehicle Colour
Format	Direction	Usage		
A*14	From club	Optional		
Remarks				
Colour of veh	icle. By default 'Un	known'		
Examples				
1110,RED				
1110,SILVER				

Record No		Status	Repetitions	Name
1111		Active	3 (Max)	Vehicle Contents
Format	Direction	Usage		
A*50	To club	Optional		
Remarks				
Can be repea	ited.			
Examples				
1111,3 PALLE	TS APPROX 4 TON	NES		
1111,EMPTY				
1111,COMPA	ACT TRACTOR INSID	E		
1111,N				

Record No		Status	Repetitions	Name
1112		Active	1 (Max)	Towing a trailer
Format	Direction	Usage		
A*1	From club	Optional		
Remarks				
Y or N. N is de	efault			

Examples 1112,N

Record No		Status	Repetitions	Name
1113		Active	1 (Max)	Gross Vehicle Mass
Format	Direction	Usage		
A*5	From club	Optional		
Remarks				
Gross weight in	kilograms			
Examples				
1113,1400				
1113,0				

Record No		Status	Repetitions	Name
1114		Active	1 (Max)	Symptom
Format	Direction	Usage		
A*50	From club	Optional		
Remarks				
As reported	by driver or previou	us attending med	hanic	
Examples				
1114,locked	in boot			
1114,NON S	TARTER . FLAT B			
1114,cows –	- dok			
1114,LONGT	OW			
1114,FUELCO	ONT			
1114,RTACO	RP			

Record No		Status	Repetitions	Name
1115		Active	1 (Max)	Tow Type
Format	Direction	Usage		
A*20	From club	Optional		
Remarks				
Eg full lift, fro	nt lift			
Examples				
1115,2WD				
1115,4WD				

Record No		Status	Repetitions	Name
1116		Active	1 (Max)	Symptom Code
Format	Direction	Usage		
A*30,A*100	From club	Optional		
Remarks				
Contains an ind	ustry standard sy	mptom code (se	e the table in this o	locument) and description, separated by a comma.
Note that it's po	ossible to send th	ne special 'OTHER	R' code with a user-	typed description if no specific symptom code is suitable
Examples				
1116,STEERING	HEAVY,Steering	heavy - power st	eering not working	
1116,OTHER,US	ser typed sympto	m description		

Record No		Status	Repetitions	Name
1117		Active	1 (Max)	Vehicle VIN (Vehicle Identification Number)
Format	Direction	Usage		
A*17	From club	Optional		
Remarks				
Contains the v	ehicle VIN numbe	r		
Examples				
1117,KMHTC6	SAD5EU213093			
1117,5NMSH1	L3E29H283187			

Record No		Status	Repetitions	Name
1118		Active	1 (Max)	Vehicle Make
Format	Direction	Usage		
A*50	From club	Optional		
Remarks				

Describes the Manufacturer of the vehicle awaiting the attendance of the work recipient. **Examples** 1118,VAUXHALL 1118,Mercedes-Benz

Record No		Status	Repetitions	Name
1119		Active	1 (Max)	Vehicle Model
Format	Direction	Usage		
A*50	From club	Optional		
Remarks				
Describes the	e Model of vehicle a	awaiting the atte	ndance of the work	recipient.
Examples				
1119,325i				
1119.OCTAV	IA VRS			

Record No		Status	Repetitions	Name
1120		Active	1 (Max)	Fuel Type
Format	Direction	Usage		
A*50	From club	Optional		
Remarks				
, ,		•		recipient, from the table below. Notice the UNSPECIFIED code which the table, the details should be entered into the notes field in this case
Examples	· ·	·		
1120,PETRO	L			
1119,DIESEL	/CNG			

# Table 1 Field 1120 Table of approved fuel types

PETROL
HEAVY OIL
ELECTRIC
STEAM
GAS
GAS BI FUEL
HYBRID ELECTRIC
GAS DIESEL
FUEL CELLS
ELECTRIC DIESEL
OTHER
ALCOHOL
CNG
DIESEL
DIESEL/CNG
DIESEL/ELECTRIC
HYDROGEN
HYDROGEN/ELECTRIC
LPG
PETROL/ALCOHOL
PETROL/CNG
PETROL/ELECTRIC
PETROL/ETHANOL
PETROL/LPG
UNSPECIFIED

Record No

Record No		Status	Repetitions	Name
1200		Active	UNKNOWN	Location
Format	Direction	Usage		
A*512	From club	Mandatory		
Remarks				
Examples				
1200,MP2376E	M4, M4 WB SAG	*£R CARDIFF , CF	3 6	
1200,MP0872E	3, M62>>WB M62(	J24->J23), APPR(	OX(2.00 KM	
1200, WINCHES	TER SERVICES SOU	JTHBOUND		

Record No		Status	Repetitions	Name
1201		Active	1 (Max)	Main Phone Number
Format	Direction	Usage		
A*22	From club	Optional		
Remarks				
Main phone r	number for job			
Examples				
1201,074469	07998			
1201,0300 11	12222			

Record No		Status	Repetitions	Name
1202		Active	1 (Max)	Location of Keys
Format	Direction	Usage		
A*50	From club	Optional		
Remarks				
By default –	'With vehicle'			
Examples				
1202,DVR				
1202,MBR				
1202,WITH F	PTL AT 177			
1202,NO KEY	/S			

1203		Active	1 (Max)	People with Car (POB) / Passengers
Format	Direction	Usage		
DD,DD,DD	From club	Optional		
Remarks				
Number of pe	ople on board, firs	st field adults, 2 <sup>n</sup>	<sup>d</sup> field children.	
New third fiel	d to contain num	per of infants (fo	r backwards con	npatibility this should be assumed to be included in the second field which
will continue t	to be the total nur	nber of children.		
Examples				
1203,1				
1203, 2,0,0				
1203,2,2,1 - i	.e. "two adults and	d two children, o	ne of whom is an	n infant"

Name

Repetitions

Status

Record No		Status	Repetitions	Name
1204		Active	1 (Max)	Special Needs
Format	Direction	Usage		
Α	From club	Optional		
Remarks				
Y/N				
Examples				
1204, N				

Record No		Status	Repetitions	Name
1205		Active	1 (Max)	Fault Code and Description
Format	Direction	Usage		
A*10, A*80	From/To club	Optional + op	tional use of secon	dary fault code and description
Remarks				
The fault code	and associated des	cription of the b	roken down vehic	le

This field can optionally contain a secondary fault code and description appended to it (see the second example below), the format for the secondary code is A\*2,A\*60

#### **Examples**

1205, LGV005,LGV Nightheater

1205, LGV005,LGV Nightheater,63,Voltage - Low

Record No		Status	Repetitions	Name
1206		Active	1 (Max)	Category of service to be provided
Format	Direction	Usage		
A*20	From club	Optional		
Remarks				
Examples				
1206, HOUSE	CALL			
1206,Y				
1206, ROADS	IDE			

Record No		Status	Repetitions	Name
1207		Active	1 (Max)	Outcome Code and Description
Format	Direction	Usage		
A*8-39	To club	Optional		
Remarks				
The outcome	e code and descript	ion as described	by the operator.	
Examples				
"1207,TOW	D2GF,RECOVERED T	O CUSTOMERS G	ARAGE"	
"1207,RACC	C,Call Clear"			

Record No		Status	Repetitions	Name
1208		Active	1(Max)	Destination Description
Format	Direction	Usage		
A*512	From/To club	Optional		
Remarks				
Examples				
1208,Always ca	ill 01206 771700 to	obtain authoris	ation before recove	ring the vehicle to:-
1208,LOCAL GA	ARAGE			
1208, **UNCO	NFIRMED** -			
1208,**PLEASE	NOTE**, IF OUT O	F FUEL THEN, LO	OCAL RECOVERY ONI	_Ү,

<b>Record No</b>		Status	Repetitions	Name	
1209		Active	1(Max)	Recovery Driver	
Format	Direction	Usage			
A*100	To club	Optional			
Remarks					
Job Recipien	ts driver used to do	the job.			
Examples					
1209,123166	õ				
1209,RAY					
1209,4THCA	LL				
1209,CANCE	LLE				

Record No		Status	Repetitions	Name
1210		Active	5(Max)	Remarks 1 <sup>st</sup> line
Format	Direction	Usage		
A*512	To club	Optional		
Remarks				
Examples				

1210, \* VEHICLE: ROVER METRO S 5/27/1993 \* FAULT: Keys locked on drivers seat

1210,,REMARKS:LAST USED 2 WEEK AGO, NUMBER IS FOR JOSEY TRANSLATOR

1210,MILEAGE-82

1210, ROADSIDE, HOME START, RELAY,

1210,[LEG:AA RESOURCE MARTYN-01138792681 LEGGING TO HARBOUR]>>MBR HAS UPGRADED TO RELAY VIA TIA AA RECOVERY PATROL MARTYN 07

<b>Record No</b>		Status	Repetitions	Name		
1211		Active	1(Max)	Vehicle Used		
Format	Direction	Usage				
A*100	To club	Optional				
Remarks						
Job Recipien	Job Recipient vehicle used to do job					
Examples						
1211,W251E	3PU(3)					
1211,LK09AF	ED(51)					

Version 4.3 – 3rd June 2020

Record No		Status	Repetitions	Name		
1212		Active	5(Max)	Notes 1st Line		
Format	Direction	Usage				
A*50	To club	Optional				
Remarks						
This field use	ed for comments no	t to be seen by cu	ıstomer/member ar	nd is therenot not normally transmitted by WP or WR.		
Examples						
1212,EA-NO	TE: ACCELERATOR N	NOT GIVING POW	ER. KEEPS DROPPIN	IG POWER, IF POSSIBLE PLEASE TRY FIX 07429237280		
1212,Cleardown Sent: 23/10/2012 by MAGS at 02:16						
1212,DAVID DEALING						
1212,btb then bcw - unit 1-2 - brackley - NN13 7EU						

Record No		Status	Repetitions	Name			
1213		Active	1(Max)	Latitude/Longitude			
Format	Direction	Usage					
A*30,AAA,DDD	From club	Optional					
Remarks							
Signed decimal lat	Signed decimal latitude and longitude .						
To be used as defa	ult for co-ordina	ates					
Examples	Examples						
1213,51.0749 , -1.8157							
1213,51.0083006694295,-2.18483768321808							
1213,51.4278, -0.	3557						

1214		Unused	1 (Max)	National Grid Coordinates	
Format	Direction	Usage			
A*20	From club	Optional			
Remarks					
Easting and I	Northing separated	by a comma			
Examples					
1214, 371500,128500					
1214,442914,316526					

Record No		Status	Repetitions	Name		
1215		Active	1(Max)	Ring on Approach (ROA) Request		
Format	Direction	Usage				
N*3	From club	Optional				
Remarks						
Specifies the	number of minutes	before expecte	d arrival at scene th	at the operator should call the member. If this field is set to 0 or is not		
present then	it means there's no	ROA required.	Maximum value is 3	120		
Examples						
"1215,0"						
"1215,10"						

Record No		Status	Repetitions	Name	
1216		New	1(Max)	Location Postcode	
Format	Direction	Usage			
A*9	From club	Optional			
Remarks					
Postcode of loc	cation (1200), if a	ailable. Can be F	Partial or Full Postco	ode	
Examples					

1216,CT118HQ 1216,DA2

Record No		Status	Repetitions	Name		
1217		Active	1 (Max)	Customer Outcome Code and Description		
Format	Direction	Usage				
A*50	To club	Optional				
Remarks						
To be used if the o	customer's outcome is di	fferent to the ve	hicle's.			
Use only from tab	le 1 below.					
Examples						
1217,HOME, Customer taken home						
1217,RAILWAY, Cu	ustomer taken to railway	station				

### Table 1 Field 1217 Table of approved customer outcome codes

GARAGE Customer with car at garage HOME Customer taken home

CARHIRE Car Hire

ACCOM Accommodation
ALTTRANSP Alternative Transport
BACKBASE Back to our SP with their car

OWNARRANGE Customer making own arrangements

HOLIDAYDEST Holiday destination
WORK Work address
ADDOTHER Address - Other
NOTFOUND Customer not found

CUSTCONT Customer continued journey

Record No		Status	Repetitions	Name			
1218		POSSIBLY INACTIVE - NOT USED IN	1 (Max)	Subcontractor Name			
		LAST MONTH					
Format	Direction	Usage					
A*50	To club	Optional					
Remarks							
To be used if Service Prov	vider subcontracts	the job					
Examples							
12nn,A Subcontractor							
12nn,A Nother Subcontra	actor						

Record No		Status	Repetitions	Name			
1219		Active	1 (Max)	Subsequent Resource Reason			
Format	Direction	Usage					
A*50	To club	Optional					
Remarks	Remarks						
To be used if the outc	ome code is "Second I	Resource Requi	red". This code will	indicate the reason for the request.			
Use only table 1 below.							
Examples							
12nn,SPEC, Specialist equipment required							

#### Table 2 Field 1219 Table of approved subsequent resource codes

SAFETY Fend off vehicle

PASSENGERS Too many passengers for original vehicle

LONGREC Long distance recovery

FULLLIFT Needs a full lift

SVCVAN Unable to repair needs recovery vehicle
CUSTOMER Customer cannot access original vehicle
VEHICLE Vehicle cannot be taken on original vehicle

SPECIALIST Second Vehicle needed that has specialist equipment

ALTVEH Customer requested alternative vehicle

EMISSIONS Vehicle type cannot enter the London emissions zone

Record No		Status	Repetitions	Name		
1220		Active	3(Max)	Terminal Message		
Format	Direction	Usage				
A*512	From/To club	Optional				
Remarks						
Used in XXX-	Used in XXX-MSG and TERM-MESS message types					
Examples						
1220.XXXPN09CA327-HI WE'VE AN UPDATED DESTINATION ON THIS ONE, VEHICLE IS GOING TO C & A CAR CARE, UNIT B3. PRENTON WAY.						

1220,XXXPN09CA327-HI WE'VE AN UPDATED DESTINATION ON THIS ONE, VEHICLE IS GOING TO C & A CAR CARE, UNIT B3, PRENTON WAY, PRENTON, CH43 3DU. CAN YOU UPDATE @ YOUR END PLEASE, CHEERS STU@A1

1220,AUTHORISATION NUMBER = 116888473Mileage authorised = 113 miles

1220,SUBJECT: Ack Message ^ Acknowledgement of message #69556291 - ^ PO29CA361 - will wait for confirmation~Grace^

Record No		Status	Repetitions	Name	
1221		Active	1(Max)	Destination Latitude / Longitude	
Format	Direction	Usage			
DD.DDDD,DD.DDDD	From club	Optional			
Remarks					
The lat/long of the loc	ation to recover	the vehicle to.			
Examples					
1221,51.0749 , -1.815	7				

Record No		Status	Repetitions	Name
1222		Active	1(Max)	Second Resource Required Flag
Format	Direction	Usage		
A*1	To Club	Optional		
Remarks				
Denotes that a	second resource	id required for th	e current job	
Examples				
1222,Y				
1222,N				

Record No		Status	Repetitions	Name		
1223		Active	1(Max)	Controller Contact		
Format	Direction	Usage				
A*25	From club	Optional				
Remarks						
Examples						
1223,MAUK\Sru						
1223,MOND	1223,MONDIAL\tpt					

Record No		Status	Repetitions	Name		
1224		Active	1(Max)	Location Co-ordinate Accuracy		
Format	Direction	Usage				
A*30,AAA,DDD	From club	Optional				
Remarks						
Accuracy (in metro	es) of the locatio	n lat/long given	in field 1213			
Examples						
1223,100.43	1223,100.43					

Record No		Status	Repetitions	Name
1225		Active	1(Max)	Alternative Phone Number
Format	Direction	Usage		
A*22	From club	Optional		
Remarks				
An alternativ	e phone number, w	vhere available. S	Should only be used	d if there are more than one phone number for the job
Examples				
"1225,07917	715869"			

Record No Status Repetitions Name

1226		Active	1(Max)	Destination Coordinate Accuracy		
Format	Direction	Usage				
A*30,AAA,DDD	From club	Optional				
Remarks						
Accuracy (in metr	es) of the destin	ation lat/long giv	en in field 1221			
Examples						
1223,100.42						

Record No		Status	Repetitions	Name		
1227		Active	1(Max)	Attendance Window Start Date Time for Pre or Re Book		
Format	Direction	Usage				
DD/MM/YY hh:mm	Both	Optional				
Remarks						
For planned bookings	, the earliest	date and time th	ne customer would	like attendance		
Examples						
1227,18/12/12 13:45	1227,18/12/12 13:45					

Record No		Status	Repetitions	Name	
1228		Active	1(Max)	Attendance Window End Date Time for Pre or Re Book	
Format	Direction	Usage			
DD/MM/YY hh:mm	Both	Optional			
Remarks					
For planned bookings	, the latest d	ate and time th	e customer would	like attendance	
Examples					
1228,18/12/12 14:45					

Record No		Status	Repetitions	Name		
1230		Active	1(Max)	Rebook permitted flag		
Format	Direction	Usage				
Α	From club	Optional				
Remarks						
Used to indica	ate that the job ma	y be re-schedule	d by the op if the c	ustomer agrees. The default is N		
Examples						
1230,Y	1230,Y					

<b>Record No</b>		Status	Repetitions	Name
1231		Active	1(Max)	Rebook Reason
Format	Direction	Usage		
Α	To club	Optional		
Remarks				
Uses only table	e (see table1)			
Examples				
1231,RJ				
1231,CC				
1231,WS				
1231,GT				

# Table 3 Field 1231 Table of approved rebook reasons

RJ Relay job CC Customer convenience

WA Weather/ accessibility of location
WS Weather/cust safe/low priority
GT Garage opening times

WV Work Volume during red alert

Record No		Status	Repetitions	Name	
1240		Active	1(Max)	Priority Flag	
Format	Direction	Usage			
Α	From club	Optional			
Remarks					
Used to indic	ate that the job ha	s elevated priorit	ty. The default is N		
Examples					
1240,Y					

Record No		Status	Repetitions	Name
1241		Active	1(Max)	Priority Reason
Format	Direction	Usage		
A*50	From club	Optional		
Remarks				
Used to indic	ate the reason for	job priority		
Examples				
1241,DLC				

#### Table 4 Field 1241 Table of approved priority reasons

DLC Dangerous Location/motorway/dual carriageway

ATF Affecting traffic flow CVU Customer Vulnerable

MHL Medical –Health/Life in danger
MOC Medic on emergency call
MSV Media sensitive/VIP
APP Important appointment
PER Important/Perishable Cargo

ACR Customer account related(eg Ambulance services)

MRC Medic on routine call

OTH Other

Record No		Status	Repetitions	Name			
1242		Active	1 (Max)	Priority Detail			
Format	Direction	Usage					
A*80	From club	Optional					
Remarks							
Additional free text detail							
Examples	Examples						
12nn,Diabetic customer without insulin							
12nn,En-route to Gatwick	airport, flight in 3	hours					

Record No		Status	Repetitions	Name
1250		Active	1(Max)	Destination postcode
Format	Direction	Usage		
Α	To club	Optional		
Remarks				
Towing desti	nation for recovery	request. Postco	de only for mileage	calculation
Examples				
1250,RH1 1P	R			

	Status	Repetitions	Name
	Active	5(Max)	Requested items from list
Direction	Usage		
To club	Optional		
		Active Usage	Active 5(Max) Direction Usage

#### Table for items used in field 1252

LAB Labour in 30 minute segments

HIA HIAB crane
SKA Skates per axle
STG Storage per day
TRM Trailer Mileage
SCA Second Callout

TOL Toll charge with amount rather than qty.

FER Ferry charges FXF Four By Four

WIN Winching in 30 minute segments

EXM Extra Man

CSV Commercial Service van hours
CR1 Commercial recovery hours level 1
CR2 Commercial recovery hours level 2
CR3 Commercial recovery hours level 3

MLG Mileage in 1 mile increments

PAR Parts charge with amount rather than qty.

Record No		Status	Repetitions	Name
1260		Active	1(Max)	Requested information (use table)
Format	Direction	Usage		
Α	From club	Optional		
Remarks				
Typically, used t	o request time up	dates, plus other	ritems	
Examples				
1260,ETA				

# Table 5 1260 request items

ETA Updated ETA requested
ATA Updated ATA requested
LAT Updated Lat/Long requested
ETC Updated ETC requested
IMG The next available Job Image

Record No		Status	Repetitions	Name	
1270		Active	1 (Max)	Axle Type	
Format	Direction	Usage			
A*10	From club	Optional			
Remarks					
Examples					
1270,LWB/SRW					
1270,LWB/TRW					
1270,SWB/SRW					
1270,SWB/TRW					

Record No		Status	Repetitions	Name
1271		Active	1 (Max)	No of Doors
Format	Direction	Usage		
A*1	From club	Optional		
Remarks				
Examples				
1271,3				
1271,4				

Record No		Status	Repetitions	Name
1272		Active	1 (Max)	Year of Registration
Format	Direction	Usage		
A*4	From club	Optional		
Remarks				
Examples				
1272,2012				

Record No		Status	Repetitions	Name
1273		Active	1 (Max)	Vehicle Height
Format	Direction	Usage		
DD.DD	From club	Optional		
Remarks				
Height in metres when v	ehicle category	is a Van or Mo	otorhome	
Examples				
1273,1.75				
1273,3.0				

Record No	Status	Repetitions	Name
1274	Active	1 (Max)	Vehicle Width

Format	Direction	Usage
DD.DD	From club	Optional
Remarks		
Width in metres w	hen vehicle category	is a Van or Motorhome
Examples		
1274,1.5		
1274,2.0		

Record No		Status	Repetitions	Name
1275		Active	1 (Max)	Vehicle Length
Format	Direction	Usage		
DD.DD	From club	Optional		
Remarks				
Length in metres who	en vehicle category is a	a Van or Motorh	nome	
Examples				
1275,4.75				
1275,6.0				

Record No		Status	Repetitions	Name	
1276		Active	1 (Max)	Trailer Type	
Format	Direction	Usage			
A*10	From club	Optional			
Remarks					
Trailer type – can be "Si	decar" if vehicle is a	a motorbike			
Examples					
1276,TRAILER					
1276,CARAVAN					
1276,SIDECAR					

Record No		Status	Repetitions	Name
1277		Active	1 (Max)	Towed Item Axle Type
Format	Direction	Usage		
A*10	From club	Optional		
Remarks				
Examples				
1277,LWB/SRW				
1277,LWB/TRW				
1277,SWB/SRW				
1277,SWB/TRW				

Record No		Status	Repetitions	Name		
1278		Active	1 (Max)	Towed Item Height		
Format	Direction	Usage				
DD.DD	From club	Optional				
Remarks						
Towed Item Height in metr	Towed Item Height in metres when vehicle is towing					
Examples						
1278,1.75						
1278,3.0						

Record No		Status	Repetitions	Name		
1279		Active	1 (Max)	Towed Item Width		
Format	Direction	Usage				
DD.DD	From club	Optional				
Remarks						
Towed Item Width in metre	Towed Item Width in metres when vehicle is towing					
Examples						
1279,1.5						
1279,2.0						

Record No Status Repetitions Name

1280		Active	1 (Max)	Towed Item Length		
Format	Direction	Usage				
DD.DD	From club	Optional				
Remarks						
Towed Item Length in me	tres when vehicle	is towing				
Examples	Examples					
1280,4.75						
1280,6.0						

Record No		Status	Repetitions	Name		
1281		Active	1 (Max)	Towed Item Weight		
Format	Direction	Usage				
DDDDD	From club	Optional				
Remarks						
Towed Item Weight in k	Towed Item Weight in kilograms when vehicle is towing					
Examples						
1281,1500						
1281,10000						

Record No		Status	Repetitions	Name
1282		Active	1 (Max)	Towed Item Load Description
Format	Direction	Usage		
A*50	From club	Optional		
Remarks				
Description of Trail	er Load.			
Examples				
1282,Garden refuse	9			
1282,Boat				

Record No		Status	Repetitions	Name	
1283		Active	1 (Max)	Prebook Reason	
Format	Direction	Usage			
A*50	From club	Optional			
Remarks					
Code, Description					
Use only from table below					
Examples					
1283,WORK,Customer at work					
1283,NONURGENT,No immediate requirement					

# Table 6 Field 1283 Table of approved pre-book reasons

HOME At Home

WORK Customer at work
APPOINT Appointment
OOHOURS Out of hours
NOTWITHVEH Not with vehicle

Record No		Status	Repetitions	Name
1284		Active	1 (Max)	Pre-book Detail
Format	Direction	Usage		
A*80	From club	Optional		
Remarks				
Additional free text detail				
Examples				
1284,cannot think of any offhand				

Record No		Status	Repetitions	Name	
1285		Active	5 (Max)	Binary Data	
Format	Direction	Usage			
A*20,A*50,A*Unlimited	To club	Optional			
Remarks					
Binary data information, for example images or PDF documents. This field is in the following format:					
	<mim< td=""><td>e type of data&gt;</td><td><file description=""> &lt;</file></td><td>Rase 64 encoded data&gt;</td></mim<>	e type of data>	<file description=""> &lt;</file>	Rase 64 encoded data>	

Common mime types are:

- image/jpeg
- application/pdf
- application/zip

See <a href="https://developer.mozilla.org/en-US/docs/Web/HTTP/Basics">https://developer.mozilla.org/en-US/docs/Web/HTTP/Basics</a> of <a href="https://developer.mozilla.org/en-US/docs/Web/HTTP/Basics">https://developer.mozilla.org/en-US/docs/Web/HTTP/Basics</a> of <a href="https://docs/web/HTTP/Basics">https://developer.mozilla.org/en-US/docs/Web/HTTP/Basics</a> of <a href="https://docs/web/HTTP/Basics">https://docs/web/HTTP/Basics</a> of <a href="https://docs/web/H

Note a limit of 500k (before base 64 encoding) is suggested for each item

#### **Examples**

1285,image/jpeg,Image [1] taken by driver,<base 64 encoded image>

# Fields 1700 - 1799: Support record types

Record No		Status	Repetitions	Name		
1752		Active	1(Max)	Software Version		
Format	Direction	Usage				
A,D.DD	From Operator	Optional				
Remarks						
Indicates the ty	Indicates the type and version of software used by the operator.					
Examples	Examples					
1752,VTRAK,4.0	1752,VTRAK,4.04					
1752,GMWin,2.	12					

#### Fields 2000 - 2999: Vehicle Telemetry Data

TICIOS EGGO ESSSI VEINGIC I	eieineti <b>y</b> E	utu			
Record No	Status	Repetitions	Name		
2000	Active	Any Number	Vehicle Current Location		
Format	Dired	tion	Usage		
A*11,A*25,DD.DD,DD.DD,dd/MM/	A*11,A*25,DD.DD,DD.DD,dd/MM/YYYY Any				
HH:mm					
Remarks					
Used in the new APX-LOC message	to specify th	e location, status	and current driver of an operators vehicle		
This is used to send out a list of the	This is used to send out a list of the operator's vehicles and their current drivers and locations. The field is repeated any number of times				
and contains the following details:					
<vehicle reg="">,<driver name="">, <vehicle latitude="">,<vehicle longitude="">,<location date="" time="">,<current job="" number=""></current></location></vehicle></vehicle></driver></vehicle>					
Examples					
"2000,GK65HFA,Andy Marks,53.23	3343455345	,-1.235456463456	5,21/10/2015 10:23,ABC12345"		

Record No	Status	Repetitions	Name		
2001	Active	1	WMTC Source ANS Node		
Format	Direct	ion	Usage		
A*7	Any				
Remarks					
Used in the APEXWMTCINIT AND APEXWMTCCANCEL messages (for where's my truck consumer) to specify the ANS node the job to be					
tracked is being carried out at. This could be different from the node the request is coming from in the case a club sends the request for					
example.					
Examples					
"2001,2000004"					

Record No	Status	Repetitions	Name
2002	Active	1	
Format	Direct	ion	Usage
D	Any		
Remarks			
Used in the APEXWMTC	INIT message to specify t	he time to live	of the where's my truck (consumer) request
Examples			
"2002,10"			

# Fields 9000 – 9999: Miscellaneous record types

Record No		Status	Repetitions	Name
9000		Active	1(Max)	Sender Station ID
Format	Direction	Usage		
A*20	From club	Optional		
Remarks				
This field's use	e is yet to be defin	ed exactly. Likely	to be the ID of the	device to which replies should be addressed.
Examples				

9000,3800425 9000,524500

Record No		Status	Repetitions	Name
9001		Active	1(Max)	Sender Station Name
Format	Direction	Usage		
A*23	From club	Optional		
Remarks				
Company Name	1			
Examples				
9001,177601				
9001,IPA				

9002		Unused	4(Max)	Sender Station Address	
Format	Direction	Usage			
A*23	From club	Optional			
Remarks					
Address					
Examples					
XXX					

9003		Unused	1(Max)	Sender Phone No	
Format	Direction	Usage			
A*22	From club	Optional			
Remarks					
Phone numb	er to call back for v	oice contact			
Examples					
XXX					

<b>Record No</b>		Status	Repetitions	Name	
9004		Active	1(Max)	Sender Name/ID	
Format	Direction	Usage			
A*20	From club	Optional			
Remarks					
Name/ID of p	Name/ID of person sending job.				
Examples					
9004,335966					
9004,JTO					

Record No		Status	Repetitions	Name		
9006		Active	1(Max)	Delay Recall Time		
Format	Direction	Usage				
A*1	From club	Optional				
Remarks						
Time in minut	Time in minutes before job is recalled					
Examples						
9006,5						

Record No		Status	Repetitions	Name
9007		Active	1(Max)	Speedo reading required?
Format	Direction	Usage		
A*1	From club	Optional		
Remarks				
Y/N. N is defau	ılt			
Examples				
9007,Y				

Record No		Status	Repetitions	Name
9008		Active	1(Max)	On-scene required?
Format	Direction	Usage		
A*1	From club	Optional		

Remarks	
Y/N. N is default	
Examples	
9008,Y	

Record No		Status	Repetitions	Name
9009		Active	1(Max)	When Clear required?
Format	Direction	Usage		
A*1	From club	Optional		
Remarks				
Y/N. N is defau	lt			
Examples				
9009,Y				

Record No		Status	Repetitions	Name	
9100		Active	1(Max)	Transaction Type	
Format	Direction	Usage			
A*20	From club	Optional			
Remarks					
Message types of 2015):	are as follows	(note the XXX pa	t can be anything bu	ut used to be to identify who the job came from and is largely unused a	
XXX-ACK		Auto-acknowled	gement of the job re	elated message from the recipient	
XXX-ETA		Job acceptance,	includes an ETA whi	ch may be zero if no ETA to be provided	
XXX-REF		Job Refusal, includes the refusal reason			
XXX-JOB		Job offer, contains details of a new job to be carried out			
XXX-UPD		Job Update, can be sent either direction contains the fields that need updating			
XXX-CLR		Job Clear-down, notifies the originator the job is complete, contains the times and outcome details			
XXX-INV		Invoice message, contains details of an invoice			
MTS-MSG		Job related message, contains the job number and some text			
TERM-MESS		Non job-related message, contains the message text			
XXX-RBK		Re-booked job op advising club			
XXX-REQ		Request for information, contains the item of info requested			
XXX-RSP		Response to a request for information message, contains the requested info			
XXX-RAU		Request for authorisation message			
XXX-LOC		Message contain	ning a list of vehicles	and their current driver and location	

9100,MTS-ACK 9100,AA-JOB

Record No		Status	Repetitions	Name
9101		Active	1(Max)	Refusal Code
Format	Direction	Usage		
A*20	To club	Optional		
Damandia				

#### Remarks

- 00, Job accepted only by computer Sender must now ring a pre-arranged telephone number with job details. Used for example in 24hr operations when the computer is put into Night Mode because the operator has gone home for the night
- 01,Too busy to deal
- 02,Not our area/wrong base chosen
- 03,Extreme weather conditions
- 04,Extreme traffic conditions
- 05,No vehicles/facilities available
- 06,No staff/ Illness / Holidays
- 07,In Dispute with organisation/Member
- 08,Unable to attend within required ETA
- 09,Unable to do recovery after roadside assist
- 10,Temporarily unavailable/off-duty/closed
- 11, Guarantee of payment not given
- 12,No License for this class
- 13,Out of Driver hours
- 14, Unable to do job/parts
- 15, Already working for this organisation
- 16,Telephone/modem no answer
- 17, Telephone/modem repeatedly engaged
- 18,Telephone/modem unobtainable/unavailable

19,Passed to fitter
100,Retransmit request
Examples
9101,00
9101,00 9101,08

Record No		Status	Repetitions	Name
9102		Active	1(Max)	Job Cancellation - Paid
Format	Direction	Usage		
A*1	From club	Optional		
Remarks				
Y/N. N is defau	ılt			
Examples				_
9102,4				

Record No		Status	Repetitions	Name	
9999		Active	1(Max)	Terminator	
Format	Direction	Usage			
A*4	From club	Mandatory			
Remarks					
The value equ	als the number of	records (apart fro	m the terminator	itself)	
Examples					
9999,4					

## Glossary

**Work provider** – A company (private or public) providing motoring assistance work to recovery operators i.e. Motoring Organisations such as AA, RAC, Inter Partner, Police Forces. A recovery operator can also be designated as a Work provider if subcontracting a job to another recovery operator.

**Work recipient** – A garage or recovery operator that performs motoring assistance functions on behalf of a Work provider.

## Appendix A – Quick Reference

0000	Invoice Number
0001	Call out Charge
0002	Mileage Charge
0003	Labour
0004	Toll Charge
0005	Hours
0006	Extra Man
0007	Service Van
0008	Parts Sold
0009	Fuel Supplied
0010	Other Charges
0011	Trailer Miles
0012	Quoted Price
0013	Invoice Sub Total
0014	VAT Amount
0015	Invoice Total
0017	Account Reference
0018	Authorised Miles
0019	Authorised Cost
0020	Authorisation Number
1000	VAT Number
1001	Agent Number

	T	
1002	Accepted by	
1003	Invoice Date	
1004	Job No	
1005	Job Date	
1006	Case Number	
1007	Job Time	
1008	ETA	
1009	Clear Time	
1010	On Scene Time	
1011	Clear Time (Elapsed)	
1012	ETA	
1013	???	
1014	Call Received Date / Time	
1015	Call Received Date	
1016	Updated ETA Supporting Text	
1017	UTC Time	
1018	Dispatch Time	
1019	Number of images available	
1020	ATA (Date + Time)	
1021	Technician Notified	
1022	Technician Accepted	
1023	Technician Location	
1024	Images Required Flag	
1025	VCRF Email Addresses	
1026	Job Distance Travelled	
1027	ETA Date Time	
1028	Technician Notified Date Time	
1029	Technician Accepted Date Time	
1030	On Route Date Time	
1031	Clear Date Time	
1032	Complete Date Time	
1033	Estimated Completion Date Time	
1100	Membership No / Cover	
1101	Clients Name	
1102	Clients Address	
1104	Vehicle Category	
1105	Vehicle Reg No	
1106	Odometer Reading	
1107	Transmission Type	
1108	Engine and Fuel Type	
1109	Drivers Location	
1110	Vehicle Colour	
1111	Vehicle Contents	
1112	Towing a trailer	
1113	Gross Vehicle Mass	
1114	Symptom	
1115	Tow Type	
1116	Symptom Code	
1117	Odometer	
1118	Vehicle Make	
1119	Vehicle Model	
1200	Location	
1201	Main Phone Number	

1202	Location of Keys		
1203	People with Car (POB)		
1204	Special Needs		
1205	Fault Code and Description		
1206	Category of service to be provided		
1207	Outcome Code and Description		
1208	Deliver to		
1209	Recovery Driver		
1210	Remarks 1 <sup>st</sup> line		
1211	Vehicle Used		
1212	Notes 1 <sup>st</sup> Line		
1213	Latitude/Longitude		
1215	Ring on Approach minutes (0 = none)		
1216	Location Postcode		
1217	Customer Outcome Code		
1218	Subcontractor Name		
1219	Subsequent Resource Reason		
1220	Terminal Message		
1221	Recover to		
1223	Controller Contact		
1224	Owner Name		
1225	Alternative phone number		
1227	Customer Agreed date/time		
1228	Customer Agreed date/time (latest)		
1230	Rebook permitted flag		
1231	Rebook Reason		
1240	Priority Flag		
1241	Priority Reason		
1242	Priority Detail		
1250	Destination postcode		
1251	Mileage requested		
1252	Requested items from list		
1260	Requested information (use table)		
1270	Axle Type		
1271	No of Doors		
1272	Year of registration		
1273	Vehicle Height		
1274	Vehicle Width		
1275	Vehicle Length		
1276	Trailer type		
1277	Towed Item Axle Type		
1278	Towed Item Height		
1279	Towed Item Width		
1280	Towed Item Length		
1281	Towed Item Weight		
1282	Towed Item Load description		
1283	Prebook reason		
1284	Prebook Detail		
1285	Binary File Data		
1752	Software Version		
2000	Vehicle Current Location		
9000	Sender Station ID		
9001	Sender Station Name		


9002	Sender Station Address
9003	Sender Phone No
9004	Sender Name/ID
9006	Delay Recall Time
9007	Speedo reading required?
9008	On-scene required?
9009	When Clear required?
9100	Transaction Type
9101	Refusal Code
9102	Job Cancellation - Paid
9999	Terminator

## Appendix B – Process Diagrams

#### **Standard Job Process**


This flowchart identifies the steps in sending a job from a JO (Job Originator) to a JR (Job Recipient) and the process of carrying out that job and associated messages. It does not show the low level ACK messages that occur for all messages sent across ANS. Note that a JO can either be a motoring organisation or an operator that is subcontracting a job to another one.

Messages involved: JOB, UPD, ETA, REF, CLR, INV



## **Job Cancellation Process**


This flowchart identifies the steps required when a JO wishes to cancel a job previously sent to a JR Messages involved: CANCEL



#### **Job Additional Authorisation Process**

This flowchart identifies the steps required when a JR requires authorisation for additional cost-incurring items on a job.


Messages involved: RAU



#### **Job Rebook Process**

This flowchart identifies the steps required when a JR wishes to notify the JO that a job has been rebooked with the end customer


Messages involved: RBK



## **Request for ATA Process**


This flowchart identifies the steps required when a JO sends a request for the JR to provide an ATA (actual time of arrival or on scene time)

Messages involved: REQ, RSP




#### **Request for Revised ETA Process**

This flowchart identifies the steps required when a JO sends a request for a revised ETA to the JR Messages involved: REQ, RSP



#### **Request for Revised ETC Process**


This flowchart identifies the steps required when a JO sends a request for a revised ETC to the JR Messages involved: REQ, RSP



#### Job Rebooked by JR Process

This flowchart identifies the steps required when a JR wishes to notify the JO that a job has been rebooked with the end customer

Messages involved: RBK



## Appendix C - Vehicle Breakdown Incident Message Flow

#### **Initial Job Transmission**

When a vehicle breakdown incident (called a job from hereon) is sent from a JO to the JR, it is sent in a JOB type message. The following is an **example** job message (note there are many more fields that could be sent this is a very simple example):

```
"9100, IPA-JOB"
"1004, IPA0412668338-1"
"1005, 13/11/12"
"1007, 10:08"
"1201, 037 9480337"
"1118, FORD"
"1118, MONDEO"
"1108, Diesel 1900cc"
"1107, Manual"
"1200, AT MCCORMACKS PETROL STATION ON MAILCOACH ROAD IN SLIGO"
"9999, 10"
```

The field 9100 denotes that this is a job message from IPA, the characters that go before the –JOB part are irrelevant and not used in most software systems nowadays.

There are several fields that are mandatory when sending a job, these are:

1004 – The unique job number, note this must be unique to the JO's system as it uniquely identifies a job from the JO to the JR, using the same job number multiple times will usually result in an update to an existing job occurring rather than a new job being created.

1005 – The date of the job in the format dd/mm/yy

1007 – The time of the job in the format HH:mm

All other fields (apart from the 9100 and 9999 fields) are optional but it is best to send as much information as possible. A full list of fields that can be sent is available in the standards document.

The AutoConnect client at the other end will send back an ACK message on receipt of this message.

#### Job Acceptance

The JR then has to either accept or reject the job given the information present in the job message. This will result in either a rejection message or an acceptance message being sent back to the JO from the JR. An acceptance message contains the expected ETA of the JR to attend the incident. A rejection message contains the reason for refusing the job chosen from a list of codes in the standard.

#### **Example Acceptance Message**

```
"9100,MTS-ETA"
"1004,GX34567"
"1005,13/11/12"
"1007,10:07"
"1012,55"
"1008,11:02"
"1027,13/11/12,11:02"
"9999,7"
```

Mandatory fields for the acceptance message are:

1004 – Job Number (as sent by the JO in the job message)

1005 – Job Date (as sent by the JO in the job message)

1007 – Job Time (as sent by the JO in the job message)

1012 – The elapsed ETA in minutes from field 1007

1008 - The ETA in time format

#### Job Rejection

### Example Rejection Message:

```
"9100,MTS-REF"
"1004,GP02920 06FE93551034"
"1005,13/11/12"
"1007,10:12"
"9101,02"
```

```
"9999,5"
```

Mandatory fields for the refusal message are:

1004 – Job Number (as sent by the JO in the job message)

1005 – Job Date (as sent by the JO in the job message)

1007 – Job Time (as sent by the JO in the job message)

9101 – The refusal code (from the list defined in the standard)

#### Job Cancellation

If a JO wants to cancel a job that has been sent it is possible to do so using the cancellation message. Note that when a job is sent from the JO to the JR quite often a timeout will be applied to the job which will auto-send a cancellation to the JR if the job hasn't been accepted within a certain time frame.

#### **Example Cancellation Message:**

```
"9100, CANCEL"
"1004, G615833"
"9999, 2"
```

The 1004 field is mandatory in the cancellation message.

#### **Revised ETA Request / Response**

If required the JO can request a revised ETA from the JR. This is done using the Request type message specifying an ETA request:

```
"9100, IPA-REQ"
"1004, IPA0413856987-1"
"1260, ETA"
"9999, 3"
```

Fields 1004 (Job Number) and 1260 (what you are requesting – ETA in this instance) are mandatory in this message

The RJ is to respond to this request with an RSP message with the ETA fields filled in:

```
"9100, APX-RSP"
"1004, 2213543856987-1"
"1008, 10:28"
"1027, 19/09/16, 10:28"
"9999, 4"
```

Fields 1004 (Job Number) and 1008/1027 (the revised ETA) are mandatory in this message

#### **Request for ATA and Response**

If required the JO can request an ATA (at scene time) for a job from the JR. This is done using the Request type message specifying an ATA request:

```
"9100,AA-REQ"
"1004,2213543856987-1"
"1260,ATA"
"9999,3"
```

Fields 1004 (Job Number) and 1260 (what you are requesting – ATA in this instance) are mandatory in this message

#### **Authorisation Request**

If a JR needs additional authorisation for cost-incurring items on a job they can request it using the RAU message:

```
9100,MTS-RAU

1004,IPA0413856987-1

1001,109265

1252,MLG, 63

1252,SKA,1

1212,Vehicle in awkward position in underground garage

1208,Haverhill Road Romford RM15

1221,52.125632434,-1.356555656

9999,8
```

Fields 1004 (Job Number), 1252 (What you are requesting) are mandatory in this message type.

The JO will then respond with a job update with the authorisation details.

#### Job updates from JR to JO

It is possible for a JR to send an update to a job to the JO, for example to update the JO of an at-scene time or change of destination. This is done using an update message type with the appropriate fields filled in:

```
"9100,MTS-UPD"
"1001,RAC8786"
"1004,RACQD16CA563"
"1005,16/12/13"
"1007,12:37"
"1020,16/12/13,12:51"
"1010,14"
"9999,7"
```

In this message the JR is updating the JO with an at-scene time denoted by the 1020 and 1010 fields being filled in. Only the 1004 job number field is mandatory in this message type although it's pretty useless if nothing else is filled in!

#### Job rebooking by a JR

It is possible for a JR to rebook a job with an end customer. If this is done a rebook message should be sent to the JO:

```
"9100, MTS-RBK"
"1004, IPA0413856987-1"
"1227, 21/03/13 14:02"
"1228, 21/03/13 14:32"
"1231, GT"
"9999, 5"
```

This message is stating that the JO that the job has been rebooked for between 14:02 and 14:32 for reason code GT (List of codes are in the ANS standards document). The 1004 (Job Number), 1227 (Earliest rebook time), 1228 (latest rebook time) and 1231 (rebook reason code) fields are mandatory in this message type.

#### Job Completion by a JR

When a job has been completed they 'clear down' the job to the JO. This is done using a clear down message type (CLR):

```
"9100, MTS-CLR"
"1004,2U4350-2631940"
"1010,13"
"1011,25"
"1008,10:46"
"1027,11/11/12,10:46"
"1009,10:58"
"1031,11/12/16,10:58"
"1010,21"
"1011,33"
"1020,13/11/12,12:46"
"1032,13/11/12,13:34"
"1106,83243"
"1205, GF26, BATTERY FLAT OTHER"
"1207, FIX17EA, EFFECT REPAIR"
"1217, GARAGE, CUSTOMER WITH CAR AT GARAGE"
"1001,3047935"
"9999,17"
```

The following fields are mandatory in this message type:

1004 (Job Number)

1010 (At scene time elapsed)

1011 (Clear time elapsed)

1009/1031 (Clear time)

1020 (At scene date / time)

If the JO requires a fault code, outcome code and vehicle speedo reading these can be sent in the appropriate fields

#### Job Invoicing

When a job is invoiced in the JR's system, if the JO's system requires ANS invoicing then an invoice message can be sent in place of a paper copy invoice:

```
"9100, MTS-INV"
```

```
"0000,60-48451"
"0001,20.00, 31.00"
"0010, 0.00,
              8.00, CLAIM HANDLING FEE
"0013, 39.00"
"0014,
       6.20"
"0015, 45.20"
"1000,GB71262575"
"1001,104369"
"1003,13/11/12"
"1004, XX37689"
"1005,13/11/12"
"1007,13:55"
"1008,14:54"
"1027,13/11/12,14:54"
"1009,14:42"
"1010,21"
"1020,13/11/12,12:46"
"1217, GARAGE, CUSTOMER WITH CAR AT GARAGE"
```

Each invoice message corresponds to a single invoice for a single job. Mandatory fields for an INV message type are: 0000 (Invoice Number)

1003 (Invoice Date)

1004 (Job Number)

0015 (Invoice Total)

0014 (VAT Amount)

0014 (VAT AITIOUTIL)

0013 (Invoice Subtotal)

1000 (JO's VAT number)

It is preferable to send back the clear down details again with the invoice message although this may be deprecated in future.

#### **Job Status Point Definitions**

#### **Issued (or Technician Notified)**

This is when a job has been passed by the job recipient to one of their drivers to carry out the job, or the job has been subcontracted to another operator for completion. It applies whether a job is sent electronically or verbally.

#### **Technician Accepted**

This is when the driver has accepted the job electronically on their device (such as a Navman unit or PDA).

#### On Route

This is triggered when the driver starts to travel to the scene of the breakdown. It's up to the operator as to what happens when the driver is carrying out multiple pickups, but we would expect that the on route would happen in this case when the pickup before the one for the job is finished.

#### At Scene

The driver has arrived at the scene of the broken down vehicle, this can be triggered electronically or verbally.

#### Clear (scene)

The driver has finished at the scene of the broken down vehicle and is leaving the scene, either with the vehicle in tow or not in the case of a roadside fix.

#### Complete

This is when, following a tow from scene the driver drops the vehicle at the final location for the job. If the driver has not towed the broken down vehicle (i.e. has fixed or left at the scene) then we would expect the complete to be carried out at the same time as clear.

#### **Back to Base**

This is triggered when a driver returns to their base depot after completing a job.

**Industry Standard Symptom Codes** 

Industry Standard S	Symptom Codes
Alarms	
ALARM / IMMOBILISER	Alarm or immobiliser system
Body	L W List Co. I
BODY	Vehicle Body
CONVERTIBLE	Roof System fault
NOISE	Noise whilst driving
SEAT BELT SMELL	Seat belt fault Unknown smell or fumes
WINDOWS	Window fault
Brakes	Willdow lault
BRAKE NOISE	Brake Pads - noise
BRAKE PEDAL	Brake Hydraulic Failure
HANDBRAKE	Handbrake failure
Charging	
ALTERNATOR	Suspected alternator
DRIVEBELT	Alternator or steering drive belt failure
Coolant	·
COOLANT LEAK	Coolant leak
HEAD GASKET	Head Gasket
OVERHEAT	High Temperature or steam
Electrical	
BATTERY	Flat battery
BATTERY LLO	Flat battery - customer confirms left light on
HORN	Horn System
LIGHTS	External light fault
WASHERS WIPERS	Windscreen Washer or Wipers
Engine	Casina failus
ENGINE	Engine failure
ENGINE NOISE ENGINE OIL	Noise from engine Oil leak
SMOKING	Smoke from exhaust
TIMING BELT	Timing belt suspected
TURBO	Turbo
EXHAUST	Exhaust Pipe
Fuel System	
FUEL ACCELERATOR	Accelerator Pedal / Cable
FUEL DIESEL	Fuel - Diesel
FUEL PETROL	Fuel - Petrol
FUEL LEAK	Fuel Leak
MISFUEL PETROL	Misfuel: Diesel in Petrol
MISFUEL DIESEL	Misfuel: Petrol in Diesel
MISFUEL OTHER	Misfuel: other e.g. add blue or water
Gearbox	
AUTO GBOX	Auto Gear Box
CLUTCH	Clutch failure
CLUTCH LINKAGE	Clutch Pedal / cable / hydraulics
GEAR LINKAGE	Gear linkage fault
GEARBOX / DRIVE DRIVESHAFT	Manual Gear Box  Driveshaft or prop shaft failure - customer verified
Heating	Privezilait or brob shart failure - customer verified
DEMISTER	Heater blower or demister not working
HV System	Treater blower of definister flot working
HV CHARGE	Electric vehicle no charge
Ignition	
CUT OUT	Cut out whilst driving
LOP	Engine runs roughly (no warning lights on)
LOP WLO	Engine runs roughly (warning lights on)
STALLING	Engine stalls at tick over
WLO ORANGE	Warning light on ORANGE - customer cannot identify
WLO RED	Warning light on RED - customer cannot identify
Keys / Locks	
KEYS LOCK OUT	Keys - Locked in vehicle
KEYS	Keys - lost by customer or stolen or broken
LOCKS	Locks jammed or cant lock / unlock
Non start	
NON START DOK	Dead on key no lights (not turning over)
NON START TONF	Turning over not firing
Other	1 a
	Driver illness or injury
ILLNESS OTHER	<ul><li>User Typed symptom can go here&gt;</li></ul>

REPATRIATION	Vehicle repatriation
Steering	
STEERING HEAVY	Steering heavy - power steering not working
STEERING FAILURE	Steering Ball Joints / Bushes
STEERING LOCK	Steering Lock / Ignition Barrel
Suspension	
SUSPENSION	Broken suspension
Trailer	
TRAILER	Fault with trailer or caravan
Wheels	
PUNCTURE	Flat tyre - Spare tyre serviceable
PUNCTURE NS	Flat tyre - Spare tyre not available
PUNCTURE FOAM	Flat tyre - with a Foam kit
PUNCTURE MULTI	Flat tyre - More than one tyre punctured
PUNCTURE BOLTS	Wheel Nuts/Bolts (Lockable) - missing or broken
WHEEL	Wheel adrift or loose
Vehicle Body (Inc. RTA & Damage)	
RTC	Road Traffic Collision
FIRE	Fire Damage
FLOOD	Driven through flood water
STOLEN	Vehicle stolen
STUCK	Car bogged down or ditched
VANDALISED	Vehicle vandalised

## **Industry Standard Fault Codes**

maasti	Standard radit codes
Alarms	
ALA001	Alarm System
ALA002	Alarm System Control Unit
ALA003	Alarm System Remote Control
ALA004	Alarm System Remote Control Miscoded
ALA005	Alarm System Remote Control Battery
ALA006	Alarm/Immobiliser (aftermarket fitted)
ALA007	Immobiliser (Customer error)
ALA008	Immobiliser (Vehicle fault)
ALA009	Transponder - Signal Interference
ALA010	Transponder System Receiver Unit
Body (inc I	RTA & Damage)
BOD001	Air Bag System
BOD002	Air Bag Warning Light
BOD003	Battery Retaining Bracket
BOD004	Bonnet / Boot Release
BOD005	Commercial Equipment/Accessories - Other
BOD006	Commercial Winch / Tail Lift
BOD007	Convertible - Power Roof Mechanism
BOD008	Convertible Hood
BOD009	Dashboard Gauges / Lighting
BOD010	Fire Damage
BOD011	Interior Trim / Fitments
BOD012	Jack / Wheel Brace
BOD013	Mirror - External
BOD014	Mirror - Rear View
BOD015	Motorcycle Frame
BOD016	Motorcycle - Kickstart
BOD017	Motorcycle - Mudguard
BOD018	Motorcycle Panniers / Fairing
BOD019	Motorcycle Support Stand
BOD020	Road Traffic Accident
500020	Noau Traine Accident

BOD021	Seat Assembly
BOD022	Seat Belt - Front
BOD023	Seat Belt - Rear
BOD024	Spare Wheel Retainer / Carrier
BOD025	Speed Sensor
BOD026	Speedometer
BOD027	Speedometer Cable
BOD028	Stolen / Vandalism
BOD029	Sun Roof System
BOD030	Tailgate
BOD031	Towing Hitch
BOD032	Underpan / Sumpguard
BOD033	Vehicle Body
BOD034	Vehicle Door / Hinges
BOD035	Vehicle Bogged / Ditched (Driveable)
BOD036	Water Damage / Flooded
BOD037	Wheel Liner
BOD037 BOD038	Window Glass Front
BOD039	Window Glass Rear
BOD040	Window Winder - Electrical/Electronic System
BOD041	Window Winder - Mechanical
BOD042	Windscreen Cleaning System
BOD043	Windscreen Wiper
BOD044	Windscreen Wiper Linkage
Brakes	
BRA001	ABS System
BRA002	ABS System Warning Light / ECU
BRA003	Brake / Load Compensator
BRA004	Brake Back Plate
BRA005	Brake Calliper (Front)
BRA006	Brake Calliper (Rear)
BRA007	Brake Disc (Front)
BRA008	Brake Disc (Rear)
BRA009	Brake Drum (Front)
BRA010	Brake Drum (Rear)
BRA011	Brake Fluid
BRA012	Brake Fluid Warning Switch
BRA013	Brakes Foreign Body Lodged
BRA014	Brake Hose
BRA015	Brake Lever (Motorcycle)
BRA016	Brake Light Relay
BRA017	Brake Light Switch
BRA017	Brake Master Cylinder / Reservoir
BRA019	Brake Pads (Front)
BRA020	Brake Pads (Rear)
BRA021	Brake Pedal
BRA022	Brake Pedal sensor
BRA023	Brake Pipe
BRA024	Brake Rod / Linkage / Cable
BRA025	Brake Servo
BRA026	Brake Shoes (Front)
BRA027	Brake Shoes (Rear)
BRA028	Brake System Vacuum Pump / Belt
BRA029	Brake System Vacuum Hose
BRA030	Brake Wheel Cylinder
BRA031	Electronic Handbrake System
BRA032	Handbrake Cable
BRA033	Handbrake Linkage
BRA034	Handbrake Ratchet And Pawl
BRA035	Handbrake Warning Light
Charging s	ystems
CHA001	Alternator
CHA002	Alternator / Charging Lamp
CHA003	Alternator / Generator Bearing
CHA004	Alternator / Generator Bearing  Alternator / Generator Bracket
CHA005	Alternator / Generator Brushes
CHA005	Alternator / Generator Drive Belt
CHA006 CHA007	Alternator / Generator Drive Belt  Alternator / Generator Drive Belt Tensioner / Idler
	Alternator / Generator Earth Strap
CHA008	
CHA009	Alternator / Generator Plug / Connection
CHA010	Alternator / Generator Pulley
CHA011	Charging System Regulator

CHA012	Charging System Relay
CHA013	Generator
CHA014 Cooling sy	Split Charging System Relay
COO001	Auxiliary Coolant Heater
COO002	Bleed Screw
COO003	Coolant
COO004	Coolant - Air In System
COO005	Coolant Expansion Tank
COO006 COO007	Coolant Filler Cap  Coolant Level Indicator
COO008	Coolant Pipe (Metal)
COO009	Coolant Temperature Sensor
COO010	Cooling Fan
COO011	Cooling Fan - Viscous Coupling
COO012	Cooling Fan Motor
COO013	Cooling Fan Relay
COO014	Cooling Fan Switch Core Plug
COO016	Hose Clip
COO017	Hose Heater
COO018	Hose Other
COO019	Hose Radiator
COO020	Radiator
COO021	Radiator Cap
COO022 COO023	Radiator Mounting Radiator Top Hose
COO023	Temperature Gauge
COO025	Thermostat
COO026	Thermostat Housing
COO027	Water Pump
COO028	Water Pump Drive Belt
COO029	Water Pump Pulley
Electrical s	Battery - Faulty Car Battery
ELEO02	Battery - Faulty Starter Motor Battery
ELE003	Battery - Faulty Auxiliary Power Battery
ELE004	Battery (Replacement Declined)
ELE005	Battery Earth Strap
ELE006	Battery Electrolyte
ELE007 ELE008	Battery Live Cable Battery Missing / Stolen
ELE009	Battery Terminals
ELE010	Body Control Unit
ELE011	Cam Bus Circuit
ELE012	Cruise Control
ELE013	Earth Strap / Earth Point
ELE014 ELE015	EKA Code Engine Bay Control Unit
ELEO15	Flat Battery (Driver Error)
ELEO17	Flat Battery (Vehicle Fault - Alarm)
ELE018	Flat Battery (Vehicle Fault - Car Phone)
ELE019	Flat Battery (Vehicle Fault - Drive Belt)
ELE020	Flat Battery (Vehicle Fault - External Lights)
ELEO21	Flat Battery (Vehicle Fault - Interior Lights)
ELE022 ELE023	Flat Battery (Vehicle Standing) Flat Battery (Vehicle Fault - other)
ELEO23	Fuse Box
ELEO25	Fuses
ELE026	Fusible Link
ELE027	Hazard Light Flasher Unit / Switch
ELE028	Heated Front Screen System
ELE029	Heated Rear Window System
ELE030 ELE031	Horn System Ignition Switch Control Unit
ELEO31	In Car - Blue tooth
ELE033	In Car - Entertainment System
ELE034	In-Car - Mobile Phone
ELE035	In Car - Satellite Navigation
ELE036	Indicator Flasher Unit
ELE037 ELE038	Indicator Switch Indicator Wiring

ELE040 Light Bulb  ELE041 Lights - Brake  ELE042 Lights - Control Unit  ELE043 Lights - Glove Box  ELE044 Lights - Head  ELE045 Lights - Indicator  ELE046 Lights - Indicator  ELE047 Lights - Luggage Compartment  ELE048 Lights - Side / Tail  ELE049 Lights - Switch  ELE050 Lights - Switch  ELE051 Main Relay  ELE052 Motorcycle - Kill Switch  ELE053 Motorcycle - Kill Switch  ELE054 Multiplug - Engine Bay  ELE055 Multiplug - Passenger Compartment  ELE056 Multiplug - Passenger Compartment  ELE057 Starter Button  ELE058 Starter Motor Relay  ELE060 Starter Motor Relay  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE070 Wiring Loom - Alternator  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG004 Crankshaft Pulley  ENG004 Engine Breather  ENG005 Engine Breather  ENG001 Engine  ENG001 Engine  ENG011 Engine Breather  ENG012 Engine Breather  ENG014 Engine Manusting  ENG014 Engine Manusting	ELEO40 ELEO41	
ELE041 Lights - Brake ELE042 Lights - Control Unit ELE043 Lights - Glove Box ELE044 Lights - Head ELE045 Lights - Indicator ELE046 Lights - Indicator ELE047 Lights - Indicator ELE048 Lights - Luggage Compartment ELE048 Lights - Relay ELE049 Lights - Switch ELE050 Lights - Switch ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Relay ELE060 Starter Motor Relay ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Alternator ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG007 Cylinder Head ENG009 Dip Stick (Engine) ENG011 Engine Breather ENG011 Engine Breather ENG012 Engine Breather ENG012 Engine Breather	ELE041	Information/Multi-Function Display
ELE042 Lights - Control Unit ELE043 Lights - Glove Box ELE044 Lights - Head ELE045 Lights - Indicator ELE046 Lights - Indicator ELE047 Lights - Luggage Compartment ELE048 Lights - Luggage Compartment ELE049 Lights - Side / Tail ELE050 Lights - Switch ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Relay ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Accessories ELE070 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft Sensor ENG003 Camshaft Pulley ENG004 Carnkshaft / Big Ends ENG007 Cylinder Head ENG009 Dip Stick (Engine) ENG011 Engine Breather		Light Bulb
ELE044 Lights - Head ELE045 Lights - Indicator ELE046 Lights - Indicator ELE047 Lights - Luggage Compartment ELE048 Lights - Relay ELE049 Lights - Side / Tail ELE050 Lights - Switch ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Alternator ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Crankshaft Pulley ENG007 Cylinder Head ENG009 Dip Stick (Engine) ENG001 Engine Earth Strap ENG001 Engine Earth Strap ENG001 Engine Earth Strap ENG001 Engine Earth Strap		
ELE044 Lights - Head ELE045 Lights - Indicator ELE046 Lights - Interior ELE047 Lights - Luggage Compartment ELE048 Lights - Relay ELE049 Lights - Side / Tail ELE050 Lights - Switch ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Passenger Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Carshshaft Pilley ENG006 Crankshaft Pilley ENG007 Cylinder Head ENG009 Dip Stick (Engine) ENG011 Engine Erath Strap ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ELE042	Lights - Control Unit
ELE045 Lights - Indicator ELE046 Lights - Interior ELE047 Lights - Luggage Compartment ELE048 Lights - Relay ELE049 Lights - Side / Tail ELE050 Lights - Switch ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Canshaft Sensor ENG005 Crankshaft / Big Ends ENG007 Cylinder Head ENG009 Dip Stick (Engine) ENG011 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ELE043	Lights - Glove Box
ELE046 Lights - Interior ELE047 Lights - Luggage Compartment ELE048 Lights - Relay ELE049 Lights - Side / Tail ELE050 Lights - Switch ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Lights ELE071 Wiring Loom - Starter ENG001 Air Intercooler ENG002 Camshaft ENG003 Cylinder Head ENG004 Crankshaft / Big Ends ENG007 Cylinder Head ENG009 Dip Stick (Engine) ENG011 Engine ENG011 Engine ENG011 Engine ENG011 Engine Breather ENG011 Engine Earth Strap ENG013 Engine Management Warning Light	ELE044	
ELE047 Lights - Luggage Compartment ELE048 Lights - Relay ELE049 Lights - Side / Tail ELE050 Lights - Switch ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Lights ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Crankshaft / Big Ends ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pluley ENG007 Cylinder Head ENG008 Cylinder Head ENG009 Dip Stick (Engine) ENG011 Engine Breather ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ELE045	Lights - Indicator
ELE048 Lights - Relay  ELE049 Lights - Side / Tail  ELE050 Lights - Switch  ELE051 Main Relay  ELE052 Motorcycle - Kill Switch  ELE053 Motorcycle Side Stand Switch  ELE054 Multiplug - Engine Bay  ELE055 Multiplug - Luggage Compartment  ELE056 Multiplug - Passenger Compartment  ELE057 Starter Button  ELE058 Starter Motor  ELE059 Starter Motor Relay  ELE060 Starter Motor Solenoid  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Atlernator  ELE070 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG011 Engine Earth Strap  ENG011 Engine Bragine Management Warning Light	ELE046	Lights - Interior
ELE048 Lights - Relay  ELE049 Lights - Side / Tail  ELE050 Lights - Switch  ELE051 Main Relay  ELE052 Motorcycle - Kill Switch  ELE053 Motorcycle Side Stand Switch  ELE054 Multiplug - Engine Bay  ELE055 Multiplug - Luggage Compartment  ELE056 Multiplug - Passenger Compartment  ELE057 Starter Button  ELE058 Starter Motor  ELE059 Starter Motor Relay  ELE060 Starter Motor Solenoid  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Atlernator  ELE070 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG011 Engine Earth Strap  ENG011 Engine Bragine Management Warning Light	ELE047	Lights - Luggage Compartment
ELE049 Lights - Side / Tail  ELE050 Lights - Switch  ELE051 Main Relay  ELE052 Motorcycle - Kill Switch  ELE053 Motorcycle Side Stand Switch  ELE054 Multiplug - Engine Bay  ELE055 Multiplug - Luggage Compartment  ELE056 Multiplug - Passenger Compartment  ELE057 Starter Button  ELE059 Starter Motor  ELE059 Starter Motor Relay  ELE060 Starter Motor Solenoid  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Wiper Control Unit  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Pulley  ENG005 Crankshaft Pulley  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light	ELE048	
ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Pulley ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG011 Engine Breather	ELE049	
ELE051 Main Relay ELE052 Motorcycle - Kill Switch ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Pulley ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG011 Engine Breather	ELE050	Lights - Switch
ELE052 Motorcycle - Kill Switch  ELE053 Motorcycle Side Stand Switch  ELE054 Multiplug - Engine Bay  ELE055 Multiplug - Luggage Compartment  ELE056 Multiplug - Passenger Compartment  ELE057 Starter Button  ELE058 Starter Motor  ELE059 Starter Motor Relay  ELE060 Starter Motor Solenoid  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Wiper Control Unit  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light	ELE051	
ELE053 Motorcycle Side Stand Switch ELE054 Multiplug - Engine Bay ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Bargine Management Warning Light		
ELE054 Multiplug - Engine Bay  ELE055 Multiplug - Luggage Compartment  ELE056 Multiplug - Passenger Compartment  ELE057 Starter Button  ELE058 Starter Motor  ELE059 Starter Motor Relay  ELE060 Starter Motor Solenoid  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light	ELE053	
ELE055 Multiplug - Luggage Compartment ELE056 Multiplug - Passenger Compartment ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG011 Engine Breather ENG012 Engine Earth Strap ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ELE054	
ELE056 Multiplug - Passenger Compartment  ELE057 Starter Button  ELE058 Starter Motor  ELE059 Starter Motor Relay  ELE060 Starter Motor Solenoid  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG000 Engine  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ELE057 Starter Button ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG012 Engine Earth Strap ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ELE058 Starter Motor ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head ENG009 Dip Stick (Engine) ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ELE059 Starter Motor Relay ELE060 Starter Motor Solenoid ELE061 Switches (other) ELE062 Tow Bar Electrics ELE063 Warning Light (only) ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Starter ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ELE060 Starter Motor Solenoid  ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft / Big Ends  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ELE061 Switches (other)  ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ELE062 Tow Bar Electrics  ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Starter  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ELE063 Warning Light (only)  ELE064 Windscreen Wiper / Washer Switch  ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ELE064 Windscreen Wiper / Washer Switch ELE065 Windscreen Wiper Motor ELE066 Wiper Control Unit ELE067 Wiper Motor Relay ELE068 Wiring Loom - Accessories ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Lights ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ELE065 Windscreen Wiper Motor  ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ELE066 Wiper Control Unit  ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		1 /
ELE067 Wiper Motor Relay  ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ELE068 Wiring Loom - Accessories  ELE069 Wiring Loom - Alternator  ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG010 Engine  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		•
ELE069 Wiring Loom - Alternator ELE070 Wiring Loom - Lights ELE071 Wiring Loom - Starter Engine ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ELE070 Wiring Loom - Lights  ELE071 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG010 Engine  ENG011 Engine Breather  ENG012 Engine Management Warning Light		
ELEO71 Wiring Loom - Starter  Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG010 Engine  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
Engine  ENG001 Air Intercooler  ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG010 Engine  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ENG001 Air Intercooler ENG002 Camshaft ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		wiring Loom - Starter
ENG002 Camshaft  ENG003 Camshaft Pulley  ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG010 Engine  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light	_	
ENG003 Camshaft Pulley ENG004 Camshaft Sensor ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ENG004 Camshaft Sensor  ENG005 Crankshaft / Big Ends  ENG006 Crankshaft Pulley  ENG007 Cylinder Head  ENG008 Cylinder Head Gasket  ENG009 Dip Stick (Engine)  ENG010 Engine  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light		
ENG005 Crankshaft / Big Ends ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ENG006 Crankshaft Pulley ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ENG004	
ENG007 Cylinder Head ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ENG008 Cylinder Head Gasket ENG009 Dip Stick (Engine) ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ENG006	Crankshaft Pulley
ENG009 Dip Stick (Engine)  ENG010 Engine  ENG011 Engine Breather  ENG012 Engine Earth Strap  ENG013 Engine Management Warning Light	ENG007	,
ENG010 Engine ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light		
ENG011 Engine Breather ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ENG009	Dip Stick (Engine)
ENG012 Engine Earth Strap ENG013 Engine Management Warning Light	ENG010	Engine
ENG013 Engine Management Warning Light	ENG011	Engine Breather
	ENG012	Engine Earth Strap
	ENG013	Engine Management Warning Light
	ENG014	Engine Mounting
ENG015 Engine Noise Unknown Reason	ENG015	Engine Noise Unknown Reason
ENG016 Engine Oil	ENG016	
ENG017 Engine Timing Chain	ENG017	Engine Timing Chain
ENG018 Engine Valve Cover Gasket	ENG018	
ENG019 Engine Valve Gear		
ENG020 Fly Wheel		
ENG021 Fly Wheel Ring Gear		
ENG022 Flywheel Sensor		
ENG023 Inlet Manifold		
ENG024 Oil Cooler		
ENG025 Oil Filler Cap		
ENG026 Oil Filter		
	ENG027	
·	ENG027 ENG028	
	ENG027 ENG028 ENG029	Oil Pressure Relay
	ENG027 ENG028 ENG029 ENG030	Oil Pressure Relay
<del>                                     </del>	ENG027 ENG028 ENG029 ENG030 ENG031	Oil Pressure Switch
	ENG027 ENG028 ENG029 ENG030 ENG031 ENG032	Oil Pressure Switch Oil Pump
	ENG027 ENG028 ENG029 ENG030 ENG031 ENG032 ENG033	Oil Pressure Switch Oil Pump Oil Seals / Gaskets
<del>                                     </del>	ENG027 ENG028 ENG029 ENG030 ENG031 ENG032 ENG033 ENG034	Oil Pressure Switch Oil Pump Oil Seals / Gaskets Oil Temperature Sensor
	ENG027 ENG028 ENG029 ENG030 ENG031 ENG032 ENG033 ENG034 ENG035	Oil Pressure Switch Oil Pump Oil Seals / Gaskets Oil Temperature Sensor Piston / Con Rod
<u> </u>	ENG027 ENG028 ENG029 ENG030 ENG031 ENG032 ENG033 ENG034 ENG035 ENG036	Oil Pressure Switch Oil Pump Oil Seals / Gaskets Oil Temperature Sensor Piston / Con Rod Secondary Air Injection Pump
ENG038 Sump	ENG027 ENG028 ENG029 ENG030 ENG031 ENG032 ENG033 ENG034 ENG035 ENG036 ENG037	Oil Pressure Switch Oil Pump Oil Seals / Gaskets Oil Temperature Sensor Piston / Con Rod Secondary Air Injection Pump Secondary Air Injection Pump Relay

ENG039	Sump Plug
ENG040	Supercharger
ENG041 ENG042	Timing Belt Timing Belt Tensioner
ENG042 ENG043	Turbo Charger / Pipes
ENG044	Turbo Pipe(s)
Exhaust	
EXH001	Catalytic Converter
EXH002	Exhaust Bracket
EXH003 EXH004	Exhaust Gas Recirculation Valve Exhaust Heat Shields
EXH005	Exhaust Manifold / Gasket
EXH006	Exhaust Pipe Centre
EXH007	Exhaust Pipe Front
EXH008	Exhaust Pipe Rear
EXH009	Exhaust Silencer
Fuel system FUE001	Accelerator Pedal
FUE002	Air / Vacuum Pipes
FUE003	Air Filter
FUE004	Air Flow / Mass Meter
FUE005	Air Temperature Sensor
FUE006	Carburetter Chake System
FUE007 FUE008	Carburettor Choke System Carburettor Diaphragm
FUE008	Carburettor Float / Needle Valve
FUE010	Carburettor Jet
FUE011	Carburettor Linkage
FUE012	Charcoal Canister
FUE013	Cold Start Injector
FUE014 FUE015	Diesel Particulate Filter  ECU - Engine Management
FUE016	ESP / Traction Control
FUE017	Fuel - Diesel (low level)
FUE018	Fuel - LPG / OTHER (low level)
FUE019	Fuel - Petrol (low level)
FUE020	Fuel Accumulator
FUE021 FUE022	Contaminated fuel petrol - NOT MISFUEL Not started Contaminated fuel diesel - NOT MISFUEL Not started
FUE023	Contaminated fuel petrol - NOT MISFUEL Started
FUE024	Contaminated fuel diesel - NOT MISFUEL Started
FUE025	Fuel Cooler
FUE026	Fuel Cut Off Solenoid
FUE027	Fuel Filler Cap Fuel Filler Pipe
FUE028 FUE029	Fuel Filter
FUE030	Fuel Flap Release Cable
FUE031	Fuel Flooded
FUE032	Fuel Gauge System
FUE033	Fuel Heater
FUE034	Fuel Hose Clip
FUE035 FUE036	Fuel Inertia Switch Fuel Injection Oxygen Sensor
FUE037	Fuel Injection Pump Ballast Resistor
FUE038	Fuel Lift Pump
FUE039	Fuel Pipes
FUE040	Fuel Pipes - Diesel
FUE041	Fuel Pressure Pagulater
FUE042 FUE043	Fuel Pressure Regulator Fuel Pressure Sensor
FUE044	Fuel Pump - Electrical
FUE045	Fuel Pump - Mechanical
FUE046	Fuel Pump Drive Belt
FUE047	Fuel Pump Relay
FUE048	Fuel Ratium Dines
FUE049	Fuel Return Pipes Fuel Tank
FUE050 FUE051	Fuel Tank Fuel Tank Sender Unit
FUE052	Fuel Tap
FUE053	Fuel Temperature Sensor
FUE054	Glow Plug
FUE055	Glow Plug Relay

FUE056	Hand Primer - Diesel
FUE057	Idle Control Stepper Motor
FUE058	Idle Speed Control Valve
FUE059	Injection Pump - Diesel
FUE060	Injection Pump - Petrol
FUE061	Injector Pipe
FUE062	Injectors - Diesel
FUE063	Injectors - Petrol
FUE064 FUE065	MAP Sensor  Misfuel: Diesel in Petrol (Engine not started)
FUE066	Misfuel: Diesel in Petrol (Engine Not started)
FUE067	Misfuel: Petrol in Diesel (Engine not started)
FUE068	Misfuel: Petrol in Diesel (Engine Started)
FUE069	Oxygen Sensor
FUE070	Thermo Time Switch
FUE071	Throttle Assembly
FUE072	Throttle Cable
FUE073	Throttle Potentiometer
FUE074	Misfuel: AdBlue in Deisel
FUE075	Misfuel: Adblue in Petrol
Gearbox /	transmission systems
GEA001	Auto Gear Box
GEA002	Auto Gear Box Inhibitor Switch
GEA003	Auto Gear Box Kickdown Control Cable
GEA004	Auto Gear Box Kickdown Switch
GEA005	Auto Gear Box Torque Converter
GEA006	Auto Gear Box Warning Light
GEA007	Clutch Clastronically Operated
GEA008	Clutch - Electronically Operated
GEA009 GEA010	Clutch Cable Clutch Fluid
GEA010	Clutch Hydraulic Pipes
GEA012	Clutch Linkage (Gearbox End)
GEA013	Clutch Linkage (Pedal End)
GEA014	Clutch Master Cylinder
GEA015	Clutch Pedal
GEA016	Clutch Pedal Switch
GEA017	Clutch Ratchet / Pawl
GEA018	Clutch Release Arm
GEA019	Clutch Release Bearing
GEA020	Clutch Slave Cylinder
GEA021	Differential (Front)
GEA022	Differential (Rear)
GEA023	Differential Oil
GEA024	Dip Stick (Transmission)
GEA025	Driveshaft  Driveshaft CV Joint
GEA026 GEA027	Driveshaft CV Joint Driveshaft CV Joint Gaiter
GEA027 GEA028	ECU - Auto Gear Box
GEA029	ECU - Transmission
GEA030	Electronic Drive Control / Selector
GEA031	Gear Box Oil
GEA032	Gear Box Oil Cooler
GEA033	Gear Lever
GEA034	Gear Linkage
GEA035	Gear Selector Cable
GEA036	Gear Selector Lock
GEA037	Gearbox Mounting
GEA038	Gearbox Sump/Filler Plug
GEA039	Manual Gear Box
GEA040	Motorcycle Chain / Sprocket / Shaft
GEA041	Prop Shaft  Sequential Goar Change System
GEA042 GEA043	Sequential Gear Change System  Traction Control (ESP) Warning Light
GEA043 GEA044	Traction Control (ESP) Warning Light Transmission 4X4 Centre Diff - Mechanical
GEA044 GEA045	Transmission 4X4 Front Diff
GEA046	Transmission 4X4 Rear Diff
GEA047	Transmission 4X4 Transfer Box / Belt
GEA048	Transmission Drive Belt
GEA049	Transmission Programming
GEA050	Transmission Viscous Coupling
GEA051	Universal Joint

Heating Sy	
HEA001 HEA002	Auxiliary Heater (Cab/Interior) Heater Controls
HEA002	Heater Matrix
HEA004	Heater Motor System
HV System	
HVT001	HV Battery
HVT002	HV Battery (out of charge)
HVT003	HV Inverter
HVT004	HV Air Conditioning
HVT005	HV Battery Casing
HVT006	HV Battery Air Cooling System
HVT007	HV Battery Liquid Cooling System
HVT008	HV Battery Temperature Sensor
HVT009	HV Cable (usually Orange)
HVT010 HVT011	HV Charging Cable HV Charging Plug (Vehicle End)
HVT012	HV Charging Plug (Supply End)
HVT013	HV Charging Fing (Supply End)
HVT014	HV Charging Socket Flap
HVT015	HV Electric Drive Motor
HVT016	HV Isolator Switch/Plug
HVT017	HV Power Distribution Unit
HVT018	HV Stage of Charge (SOC) Indicator
HVT019	HV Warning Light - Charging
HVT020	HV Warning Light - Battery
HVT021	HV Warning Light - Motor
HVT022	HV Warning Light - Coolant Temperature
HVT023	HV Warning Light - System (Master Warning)
Ignition IGN001	Coil
IGN001	Coil - Cyl 1 from Timing Chain End
IGN002	Coil - Cyl 2 from Timing Chain End
IGN004	Coil - Cyl 3 from Timing Chain End
IGN005	Coil - Cyl 4 from Timing Chain End
IGN006	Coil - Cyl 5 from Timing Chain End
IGN007	Coil - Cyl 6 from Timing Chain End
IGN008	Coil - Individual (All cylinders replaced)
IGN009	Coil Pack
IGN010	Crankshaft Sensor
IGN011	Distributor
IGN012	Distributor Cap
IGN013	Distributor Drive
IGN014	Distributor Rotor Arm ECU Engine Management
IGN015 IGN016	ECU Ignition System
IGN018 IGN017	HT Leads
IGN017	
	I Ignition Ambillier
IGN019	Ignition Amplifier Ignition Relay
IGN019 IGN020	
	Ignition Relay
IGN020	Ignition Relay Ignition Reluctor / Hall Sensor
IGN020 IGN021 IGN022 IGN023	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp
IGN020 IGN021 IGN022 IGN023 IGN024	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005 KEY006	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid Central Locking Switches Deadlocks
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005 KEY006 KEY007	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid Central Locking Switches
IGN020 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005 KEY006 KEY007 KEY008	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid Central Locking Switches Deadlocks Immobiliser - Control Unit
IGN020 IGN021 IGN021 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005 KEY006 KEY007 KEY008 KEY009	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid Central Locking Switches Deadlocks Immobiliser - Control Unit
IGN020 IGN021 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005 KEY006 KEY007 KEY008 KEY009 KEY010 KEY011 KEY012	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid Central Locking Switches Deadlocks Immobiliser - Control Unit Immobiliser - Hechanical Key - Blade Key - Electronic Card
IGN020 IGN021 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005 KEY006 KEY007 KEY008 KEY009 KEY010 KEY011 KEY012 KEY012 KEY013	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid Central Locking Switches Deadlocks Immobiliser - Control Unit Immobiliser - Blectrical Immobiliser - Mechanical Key - Blade Key - Electronic Card Key - Mechanical
IGN020 IGN021 IGN021 IGN022 IGN023 IGN024 IGN025 IGN026 Keys, Lock KEY001 KEY002 KEY003 KEY004 KEY005 KEY006 KEY007 KEY008 KEY009 KEY010 KEY011 KEY012	Ignition Relay Ignition Reluctor / Hall Sensor Ignition Switch Ignition System Ballast Resistor Ignition System Damp Knock Sensor Points / Condenser Spark Plugs s & Security Central Locking Central Locking Control Unit Central Locking Relay Central Locking Remote Control Central Locking Solenoid Central Locking Switches Deadlocks Immobiliser - Control Unit Immobiliser - Hechanical Key - Blade Key - Electronic Card

KEY016 Keys - Locked in Boot/Luggage Compartment KEY017 Keys - Locked in Engine Compartment KEY018 Keys - Locked in Passenger Compartment KEY019 Keys - Isos by customer KEY020 Keys - stolen KEY021 Lock - Bonnet KEY022 Lock - Doors KEY023 Lock - Luggage Compartment KEY024 Locking Wheel Nut Key KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV UGV I LGV contaminated fuel LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Midguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Pump Belt STE003 Power Steering Pump Belt STE004 Power Steering Pump Belt STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Rack / Ram STE009 Power Steering Rack / Ram STE001 Steering Ball Joints / Bushes STE013 Steering Ball Joints / Bushes STE014 Steering Ball Joints / Bushes STE015 Steering Ball Joints / Bushes STE016 Steering Rack / Ram STE017 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS001 Active Corner Enhancement SUS001 Active Corner Enhancement SUS000 Active Corner Enhancement SUS000 Active Corner Enhancement SUS000 Active Corner Enhancement
KEY018 Keys - Locked in Passenger Compartment KEY019 Keys - Iost by customer KEY020 Keys - stolen KEY021 Lock - Bonnet KEY022 Lock - Doors KEY023 Lock - Luggage Compartment KEY024 Locking Wheel Nut Key KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mirror LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Customer Illness) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pump - Mechanical STE004 Power Steering Pump Belt STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE000 Power Steering Pump Belt STE001 Steering Ball Joints / Bushes STE013 Steering Ball Joints / Bushes STE014 Steering Bamper STE015 Steering Bander STE015 Steering Bander STE016 Steering Bander STE017 Steering Wheel SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY019 Keys - lost by customer KEY020 Keys - stolen KEY021 Lock - Bonnet KEY022 Lock - Doors KEY023 Lock - Luggage Compartment KEY024 Locking Wheel Nut Key KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV003 LGV Mirror LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pump Pelt STE004 Power Steering Pump Pelt STE005 Power Steering Pump Belt TSE007 Power Steering Pump Belt STE007 Power Steering Pump Pipes STE001 Power Steering Raservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball points / Bushes STE013 Steering Bampe STE014 Steering Bampe STE015 Steering Bampe STE015 Steering Bampe STE016 Steering Bampe STE017 Steering Bampe STE017 Steering Bampe STE017 Steering Bampe STE016 Steering Bampe STE017 Steering Bampe STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY020 Keys - stolen KEY021 Lock - Bonnet KEY022 Lock - Doors KEY023 Lock - Luggage Compartment KEY024 Locking Wheel Nut Key KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV LGV Contaminated fuel LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Migror LGV004 LGV Mudguards LGV005 LGV Ringtheater LGV005 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pump Belt STE004 Power Steering Pump Belt STE005 Power Steering Pump Belt Tensioner / Idler STE006 Power Steering Pump Belt Tensioner / Idler STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Belt Tensioner / Idler STE009 Power Steering Pump Belt Tensioner / Idler STE001 Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Barper STE014 Steering Barper STE015 Steering Barper STE016 Steering Barper STE017 Steering Damper STE017 Steering Damper STE016 Steering Damper STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY022 Lock - Doors KEY023 Lock - Doors KEY023 Lock - Doors KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mirror LGV005 LGV Nightheater LGV005 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Transmission LGV009 LGV Transmission LGV009 LGV Brakes LGV009 LGV Erakes LGV010 LGV Erakes LGV010 LGV Brakes LGV010 LGV Brakes LGV010 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Plead STE003 Power Steering Pump Belt STE004 Power Steering Pump Belt STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Reservoir / Cap / Indicator STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel SUS001 Active Corner Enhancement SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY022 Lock - Doors KEY023 Lock - Luggage Compartment KEY024 Locking Wheel Nut Key KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV009 LGV Transmission LGV009 LGV Transmission LGV010 LGV Brakes LGV010 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Plead STE003 Power Steering Pump Hechanical STE004 Power Steering Pump Belt Tensioner / Idler STE005 Power Steering Pump Belt Tensioner / Idler STE006 Power Steering Pump Belt Tensioner / Idler STE007 Power Steering Reservoir / Cap / Indicator STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Column STE015 Steering Lock / Ignition Barrel STE016 Steering Baren STE017 Steering Wheel SUS001 Active Corner Enhancement SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY023 Lock - Luggage Compartment KEY024 Locking Wheel Nut Key KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pump Belt STE004 Power Steering Pump Belt STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE008 Power Steering Pump Belt STE009 Power Steering Pump Belt STE009 Power Steering Reservoir / Cap / Indicator STE011 Steering Ball Joints / Bushes STE013 Steering Ball Joints / Bushes STE014 Steering Bamper STE015 Steering Bamper STE015 Steering Bamper STE016 Steering Bamper STE017 Steering Bamper STE017 Steering Bamper STE018 Steering Bamper STE019 Steering Bamper STE010 Steering Bamper STE010 Steering Bamper STE011 Steering Bamper STE013 Steering Bamper STE015 Steering Bake / Bam STE016 Steering Bamper STE017 Steering Bamper STE017 Steering Bamper STE018 Steering Bamper STE019 Steering Bamper STE019 Steering Bamper STE010 Steering Bamper STE011 Steering Bamper STE013 Steering Bamper
KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV010 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Plump STE004 Power Steering Pump Belt STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE009 Power Steering Reservoir / Cap / Indicator STE010 Steering Ball Joints / Bushes STE011 Steering Ball Joints / Bushes STE012 Steering Ball Joints / Bushes STE013 Steering Ball Joints / Bushes STE014 Steering Bamper STE015 Steering Banper STE015 Steering Banper STE016 Steering Banper STE017 Steering Banper STE018 Steering Banper STE019 Steering Banper STE010 Steering Banper STE010 Steering Banper STE011 Steering Banper STE012 Steering Banper STE013 Steering Ball Joints / Bushes STE014 Steering Banper STE015 Steering Banper STE016 Steering Back / Box STE017 Steering Bark / Box STE018 Steering Banper STE019 Steering Banper STE010 Steering Banper STE010 Steering Banper STE011 Steering Damper STE012 Steering Banper STE013 Steering Back / Box STE014 Steering Damper STE015 Steering Back / Box STE016 Steering Back / Box STE017 Steering Subheel SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY025 Removable Security Locks / Devices KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pump Head STE004 Power Steering Pump Belt Tensioner / Idler STE005 Power Steering Pump Belt Tensioner / Idler STE006 Power Steering Pump Belt Tensioner / Idler STE007 Power Steering Pump Pipes STE009 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Back / Box STE016 Steering Back / Box STE017 Steering Mheel SUS001 Active Corner Enhancement SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY026 Security Locks (aftermarket fitted) KEY027 Transponder Chip LGV LGV USV Contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE001 Electric/Electronic Power Steering System STE003 Power Steering Pulley STE004 Power Steering Pump Belt STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE008 Power Steering Reservoir / Cap / Indicator STE010 Power Steering Reservoir / Cap / Indicator STE011 Steering Ball Joints / Bushes STE013 Steering Lock / Ignition Barrel STE015 Steering Lock / Ignition Barrel STE017 Steering Melel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
KEY027 Transponder Chip LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pulley STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Belt Tensioner / Idler STE009 Power Steering Reservoir / Cap / Indicator STE010 Power Steering Reservoir / Cap / Indicator STE011 Steering Ball Joints / Bushes STE012 Steering Ball Joints / Bushes STE013 Steering Lock / Ignition Barrel STE015 Steering Lock / Ignition Barrel STE016 Steering Back / Box STE017 Steering Meel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pump Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE007 Power Steering Reservoir / Cap / Indicator STE010 Steering Ball Joints / Bushes STE011 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Back / Ram STE015 Steering Back / Box STE017 Steering Rack / Box STE017 Steering Melel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV001 LGV contaminated fuel LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Range Change Fault LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pulley STE005 Power Steering Pump Belt STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE009 Power Steering Reservoir / Cap / Indicator STE010 Steering Ball Joints / Bushes STE011 Steering Ball Joints / Bushes STE015 Steering Back / Ram STE016 Steering Ball Joints / Bushes STE017 Steering Damper STE015 Steering Back / Box STE017 Steering Melel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV002 LGV Fridge Fault LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Rack / Ram STE010 Power Steering Rack / Ram STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Back / Box STE017 Steering Rack / Box STE017 Steering Melel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV003 LGV Mirror LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE008 Power Steering Pump Belt STE009 Power Steering Rack / Ram STE010 Power Steering Rack / Ram STE010 Power Steering Ball Joints / Bushes STE011 Steering Ball Joints / Bushes STE014 Steering Damper STE015 Steering Damper STE016 Steering Rack / Ignition Barrel STE017 Steering Rack / Box STE017 Steering Wheel
LGV004 LGV Mudguards LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE009 Power Steering Pump Belt STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Back / Box STE017 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV005 LGV Nightheater LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt STE008 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Back / Box STE017 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV006 LGV Range Change Fault LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Raservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV007 LGV Suzies LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Reservoir / Cap / Indicator STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV008 LGV Accident LGV009 LGV Transmission LGV010 LGV Brakes LGV011 LGV Exhaust Brake Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Ball Joints / Bushes STE012 Steering Damper STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
LGV010 LGV Brakes LGV011 LGV Exhaust Brake  Other  OTH001 No Component Identified  OTH002 No fault found with vehicle at time of test  OTH003 No Trace  OTH004 Member Cancelled  OTH005 Vehicle Repatriation (Customer Illness)  OTH006 Vehicle Repatriation (Repaired vehicle)  OTH007 Non motoring service provided  Steering  STE001 Electric/Electronic Power Steering System  STE002 Motorcycle Steering Head  STE003 Power Steering Oil Cooler  STE004 Power Steering Pulley  STE005 Power Steering Pump - Mechanical  STE006 Power Steering Pump Belt  STE007 Power Steering Pump Belt Tensioner / Idler  STE008 Power Steering Rack / Ram  STE010 Power Steering Reservoir / Cap / Indicator  STE011 Power Steering Ball Joints / Bushes  STE012 Steering Damper  STE014 Steering Damper  STE015 Steering Lock / Ignition Barrel  STE017 Steering Wheel  Suspension  SUS001 Active Corner Enhancement  SUS002 Active Suspension System
Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Pulley STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Ball Joints / Bushes STE012 Steering Damper STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
Other OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
OTH001 No Component Identified OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
OTH002 No fault found with vehicle at time of test OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Damper STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
OTH003 No Trace OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided  Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Rack / Ram STE010 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
OTH004 Member Cancelled OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided  Steering  STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head  STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
OTH005 Vehicle Repatriation (Customer Illness) OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided  Steering  STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head  STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
OTH006 Vehicle Repatriation (Repaired vehicle) OTH007 Non motoring service provided  Steering  STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head  STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical  STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
OTH007 Non motoring service provided  Steering  STE001 Electric/Electronic Power Steering System  STE002 Motorcycle Steering Head  STE003 Power Steering Oil Cooler  STE004 Power Steering Pulley  STE005 Power Steering Pump - Mechanical  STE006 Power Steering Pump Belt  STE007 Power Steering Pump Belt Tensioner / Idler  STE008 Power Steering Pump Pipes  STE009 Power Steering Rack / Ram  STE010 Power Steering Reservoir / Cap / Indicator  STE011 Power Steering Hydraulic Fluid  STE012 Steering Ball Joints / Bushes  STE013 Steering Column  STE014 Steering Damper  STE015 Steering Lock / Ignition Barrel  STE016 Steering Rack / Box  STE017 Steering Wheel  Suspension  SUS001 Active Corner Enhancement  SUS002 Active Suspension System
Steering STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Raservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE001 Electric/Electronic Power Steering System STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE002 Motorcycle Steering Head STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE003 Power Steering Oil Cooler STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE004 Power Steering Pulley STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE005 Power Steering Pump - Mechanical STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE006 Power Steering Pump Belt STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE007 Power Steering Pump Belt Tensioner / Idler STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE008 Power Steering Pump Pipes STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE009 Power Steering Rack / Ram STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE010 Power Steering Reservoir / Cap / Indicator STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE011 Power Steering/Hydraulic Fluid STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE012 Steering Ball Joints / Bushes STE013 Steering Column STE014 Steering Damper STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE014 Steering Damper  STE015 Steering Lock / Ignition Barrel  STE016 Steering Rack / Box  STE017 Steering Wheel  Suspension  SUS001 Active Corner Enhancement  SUS002 Active Suspension System
STE015 Steering Lock / Ignition Barrel STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE016 Steering Rack / Box STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
STE017 Steering Wheel Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
Suspension SUS001 Active Corner Enhancement SUS002 Active Suspension System
SUS001 Active Corner Enhancement SUS002 Active Suspension System
SUS002 Active Suspension System
505003   Air Suspension
·
SUS004 Air Suspension Compressor SUS005 Air Suspension Drive Belt
SUS005 Air Suspension Drive Belt SUS006 Air Suspension Drive Belt Tensioner / Idler
SUS007 Air Suspension Pipe
SUS008 Anti-Roll Bar / Bushes
SUS009 Hydraulic Suspension System
SUS010 Motorcycle Forks
SUS011 Motorcycle Swinging Arm
SUS012 Shock Absorber
SUS013 Subframe
SUS014 Suspension - ECU
SUS015 Suspension Height Sensor NSF
SUS016 Suspension Height Sensor OSF
SUS017 Suspension Height Sensor NSR
SSSEZ/ Suspension ricigite School Note
SUS018 Suspension Height Sensor OSR
SUS018 Suspension Height Sensor OSR SUS019 Suspension Spring Front
SUS018 Suspension Height Sensor OSR

Trailer & Caravan TRA001 Trailer / caravan A Frame TRA002 Trailer / caravan accident TRA003 Trailer / caravan accident TRA004 Trailer / caravan akle TRA005 Trailer / caravan body parts TRA006 Trailer / caravan lectrics TRA006 Trailer / caravan jockey wheel TRA007 Trailer / caravan lights TRA008 Trailer / caravan over run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan wheel bearing TRA013 Trailer / caravan wheel brakes TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE001 Tyre (No spare provided as original equipment) WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Five) WHE000 Tyres (Three) WHE010 Tyres (Three) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE016 Wheel Nuts / Bolts / Studs WHE017 Wheel Nuts / Bolts / Studs WHE016 Wheel Nuts / Bolts / Studs WHE017 Wheel Nuts / Bolts / Studs WHE016 Wheel Nuts / Bolts / Studs WHE017 Wheel Nuts / Bolts / Studs	CLICO22	Consequence Windsham
TRA001 Trailer / caravan A Frame TRA002 Trailer / caravan accident TRA003 Trailer / caravan accident TRA004 Trailer / caravan body parts TRA005 Trailer / caravan body parts TRA006 Trailer / caravan electrics TRA006 Trailer / caravan lectrics TRA007 Trailer / caravan lights TRA008 Trailer / caravan power run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan socket / plug TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel brakes TRA016 Trailer / caravan wheel brakes TRA017 Trailer / caravan wheel brakes TRA018 Trailer / caravan wheel brakes TRA019 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE001 Tyres (Three) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE015 Wheel Nuts / Bolts / Studs	SUS022	Suspension Wishbone
TRA002 Trailer / caravan accident TRA003 Trailer / caravan axle TRA004 Trailer / caravan body parts TRA005 Trailer / caravan body parts TRA006 Trailer / caravan electrics TRA007 Trailer / caravan jockey wheel TRA007 Trailer / caravan lights TRA008 Trailer / caravan over run brake TRA009 Trailer / caravan over run brake TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel braing TRA015 Trailer / caravan wheel brakes TRA016 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE015 Wheel Nuts / Bolts / Studs		
TRA003 Trailer / caravan axle TRA004 Trailer / caravan body parts TRA005 Trailer / caravan electrics TRA006 Trailer / caravan jockey wheel TRA007 Trailer / caravan lights TRA008 Trailer / caravan over run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan wheel bearing TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change  Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE015 Wheel Nuts / Bolts / Studs		•
TRA004 Trailer / caravan body parts TRA005 Trailer / caravan electrics TRA006 Trailer / caravan electrics TRA007 Trailer / caravan lights TRA008 Trailer / caravan lights TRA009 Trailer / caravan over run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Five or more) WHE009 Tyres (Five or more) WHE010 Tyres (Three) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE015 Wheel Hub WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs		
TRA005 Trailer / caravan electrics TRA006 Trailer / caravan jockey wheel TRA007 Trailer / caravan lights TRA008 Trailer / caravan over run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan suspension units TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel brakes TRA016 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Valve WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Five or more) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE015 Wheel Hub WHE015 Wheel Hub WHE015 Wheel Nuts / Bolts / Studs		·
TRA006 Trailer / caravan jockey wheel TRA007 Trailer / caravan lights TRA008 Trailer / caravan over run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Five or more) WHE009 Tyres (Three) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs		
TRA007 Trailer / caravan lights TRA008 Trailer / caravan over run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE015 Wheel Hub WHE015 Wheel Hub WHE015 Wheel Nuts / Bolts / Studs		•
TRA008 Trailer / caravan over run brake TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change  Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Five or more)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE015 Wheel Nuts / Bolts / Studs		
TRA009 Trailer / caravan puncture no spare TRA010 Trailer / caravan suspension units TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change  Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE015 Wheel Nuts / Bolts / Studs		_
TRA010 Trailer / caravan suspension units  TRA011 Trailer / caravan socket / plug  TRA012 Trailer / caravan tow hitch  TRA013 Trailer / caravan wheel bearing  TRA014 Trailer / caravan wheel brakes  TRA015 Trailer / caravan wheel change  Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE015 Wheel Nuts / Bolts / Studs		
TRA011 Trailer / caravan socket / plug TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change Ventilation VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs		
TRA012 Trailer / caravan tow hitch TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change  Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE015 Wheel Nuts / Bolts / Studs		
TRA013 Trailer / caravan wheel bearing TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change  Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE016 Wheel Nuts / Bolts / Studs		
TRA014 Trailer / caravan wheel brakes TRA015 Trailer / caravan wheel change  Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE015 Wheel Nuts / Bolts / Studs		•
TRA015 Trailer / caravan wheel change  Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE016 Wheel Nuts / Bolts / Studs	TRA013	Trailer / caravan wheel bearing
Ventilation  VEN001 Air Conditioning Compressor  VEN002 Air Conditioning Drive Belt  VEN003 Air Conditioning Drive Belt Tensioner / Idler  VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE016 Wheel Nuts / Bolts / Studs		•
VEN001 Air Conditioning Compressor VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE015 Wheel Hub		•
VEN002 Air Conditioning Drive Belt VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE015 Wheel Hub WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	Ventilation	1
VEN003 Air Conditioning Drive Belt Tensioner / Idler VEN004 Air Conditioning System VEN005 Pollen Filter Wheels WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	VEN001	Air Conditioning Compressor
VEN004 Air Conditioning System  VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE016 Wheel Nuts / Bolts / Studs	VEN002	Air Conditioning Drive Belt
VEN005 Pollen Filter  Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE016 Wheel Nuts / Bolts / Studs	VEN003	Air Conditioning Drive Belt Tensioner / Idler
Wheels  WHE001 Spare Wheel  WHE002 Stub Axle  WHE003 Tyre  WHE004 Tyre (No spare provided as original equipment)  WHE005 Tyre Pressure Warning System  WHE006 Tyre Valve  WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE016 Wheel Nuts / Bolts / Studs	VEN004	Air Conditioning System
WHE001 Spare Wheel WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	VEN005	Pollen Filter
WHE002 Stub Axle WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	Wheels	
WHE003 Tyre WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE001	Spare Wheel
WHE004 Tyre (No spare provided as original equipment) WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE002	Stub Axle
WHE005 Tyre Pressure Warning System WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE003	Tyre
WHE006 Tyre Valve WHE007 Tyres (Five or more) WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE004	Tyre (No spare provided as original equipment)
WHE007 Tyres (Five or more)  WHE008 Tyres (Four)  WHE009 Tyres (Three)  WHE010 Tyres (Two)  WHE011 Tyres - spare unserviceable  WHE012 Wheel  WHE013 Wheel Bearing Front  WHE014 Wheel Bearing Rear  WHE015 Wheel Hub  WHE016 Wheel Nuts / Bolts / Studs	WHE005	Tyre Pressure Warning System
WHE008 Tyres (Four) WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE006	Tyre Valve
WHE009 Tyres (Three) WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE007	Tyres (Five or more)
WHE010 Tyres (Two) WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE008	Tyres (Four)
WHE011 Tyres - spare unserviceable WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE009	Tyres (Three)
WHE012 Wheel WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE010	Tyres (Two)
WHE013 Wheel Bearing Front WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE011	Tyres - spare unserviceable
WHE014 Wheel Bearing Rear WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE012	Wheel
WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE013	Wheel Bearing Front
WHE015 Wheel Hub WHE016 Wheel Nuts / Bolts / Studs	WHE014	Wheel Bearing Rear
	WHE015	
WHE017 Wheel Nuts/Bolts (Lockable)	WHE016	Wheel Nuts / Bolts / Studs
, , ,	WHE017	Wheel Nuts/Bolts (Lockable)

# Industry Standard Secondary Fault Codes O1 Adjusted

01	Adjusted
02	Air Ingress
03	Air Leakage
04	Bearing failed
05	Battery - Test Failed
06	Battery - Test Passed
07	Blocked
08	Blown
09	Broken (component)
10	Broken (wire)
11	Burnt
12	Chaffed
13	Chemical Test failed (cylinder head gasket)
14	Collapsed
15	Contaminated (fluid)
16	Contaminated (other)
17	Corroded
18	Cracked
19	Customer Repair Inadequate
20	Damaged
21	Damaged (RTC Insured Incident)
22	Disconnected
23	Driver error (fault caused by customer)
24	Flooded (Fuel)
25	Flooded (Water)
26	Fluid Level Low
27	Frozen

29 Incorrectly fitted part 30 Jammed 31 Leaking / Fluid Loss 32 Left on (driver fault) 33 Left on (vehicle fault) 34 Loose 35 Lost 36 Misfiring 37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - High 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	28	Incorrect part fitted
30 Jammed 31 Leaking / Fluid Loss 32 Left on (driver fault) 33 Left on (vehicle fault) 34 Loose 35 Lost 36 Misfiring 37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		•
31 Leaking / Fluid Loss 32 Left on (driver fault) 33 Left on (vehicle fault) 34 Loose 35 Lost 36 Misfiring 37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
32 Left on (driver fault) 33 Left on (vehicle fault) 34 Loose 35 Lost 36 Misfiring 37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
Jeft on (vehicle fault)  Jeft on (vehicle fault)  Loose  Jicost  Misfiring  Misfuel  Missing - part  Multi-plug fault  Not disarming  Lopen Circuit  Jour of correct fuel  Voerfilled  Pressure - High  Pressure - Low  Resistance - earth  Resistance - High  Resistance - High  Resistance - Low  Seized  Shorted out  Shredded  Slipping  Stolen  Junoadworthy  Unsynchronised  Vandalised  Voltage - Low  Varling Light Displayed  Warning Light Displayed	_	
34 Loose 35 Lost 36 Misfiring 37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	_	, ,
35 Lost 36 Misfiring 37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		,
36 Misfiring 37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	_	
37 Misfuel 38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
38 Missing - part 39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		<u> </u>
39 Multi-plug fault 40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
40 Not disarming 41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
41 Not engaging 42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		. •
42 Open Circuit 43 Out of correct fuel 44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
43 Out of correct fuel  44 Overfilled  45 Poor connection  46 Pressure - High  47 Pressure - Low  48 Punctured  49 Resistance - earth  50 Resistance - High  51 Resistance - Low  52 Seized  53 Shorted out  54 Shredded  55 Slipping  56 Stolen  57 Suspected - further diagnosis required to confirm fault  58 Unroadworthy  59 Unsynchronised  60 Vandalised  61 Vibration  62 Voltage - High  63 Voltage - Low  64 Warning Light Displayed  65 Water Ingress / Damp		
44 Overfilled 45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
45 Poor connection 46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
46 Pressure - High 47 Pressure - Low 48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		0.101.111100
47 Pressure - Low  48 Punctured  49 Resistance - earth  50 Resistance - High  51 Resistance - Low  52 Seized  53 Shorted out  54 Shredded  55 Slipping  56 Stolen  57 Suspected - further diagnosis required to confirm fault  58 Unroadworthy  59 Unsynchronised  60 Vandalised  61 Vibration  62 Voltage - High  63 Voltage - Low  64 Warning Light Displayed  65 Water Ingress / Damp		
48 Punctured 49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		Pressure - High
49 Resistance - earth 50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	47	Pressure - Low
50 Resistance - High 51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	48	Punctured
51 Resistance - Low 52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		
52 Seized 53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp		Resistance - High
53 Shorted out 54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	51	Resistance - Low
54 Shredded 55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	52	Seized
55 Slipping 56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	53	Shorted out
56 Stolen 57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	54	Shredded
57 Suspected - further diagnosis required to confirm fault 58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	55	Slipping
58 Unroadworthy 59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	56	Stolen
59 Unsynchronised 60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	57	Suspected - further diagnosis required to confirm fault
60 Vandalised 61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	58	Unroadworthy
61 Vibration 62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	59	Unsynchronised
62 Voltage - High 63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	60	Vandalised
63 Voltage - Low 64 Warning Light Displayed 65 Water Ingress / Damp	61	Vibration
64 Warning Light Displayed 65 Water Ingress / Damp	62	Voltage - High
64 Warning Light Displayed 65 Water Ingress / Damp	63	Voltage - Low
65 Water Ingress / Damp	64	
CC Maria	65	
ן אסרוו	66	Worn

## **Industry Standard Outcome Codes**

Repairs	
FIX01	Roadside Repair: By-passed Component
FIX02	Roadside Repair: Battery Replaced
FIX03	Roadside Repair: Replaced Other Component
FIX04	Roadside Repair: Temporary Repair
FIX05	Roadside Repair: Permanent Repair
FIX06	Roadside Repair: Reset to Correct Value/Level
FIX07	Roadside Repair: Re-Filled
FIX08	Roadside Repair: Battery Boosted
FIX09	Roadside Repair: Effect Entry
FIX10	Roadside Repair: Wheel Change
FIX11	Roadside Repair: Reprogrammed/Resynchronised
FIX12	Roadside Repair: Tyre Replacement Service
FIX13	Roadside Repair: Contaminated Fuel Drain
FIX14	Vehicle Mobile & Roadworthy - No Repair Nec'y
FIX15	Winch Vehicle to hard standing
FIX16	Roadside Repair: No Fault found
FIX17	Repaired at contractor workshop (Motoring Organisation to pay)
FIX18	Repaired at contractor workshop (Customer to pay)
FIX19	Roadside Repair feasible customer refused
FIX20	Workshop Repair feasible same day customer refused
Non-Repairs / Recoveries	
TOW01	Customer declined recovery advised no service available
TOW02	Customer requesting deferred recovery accepted under policy
TOW03	Tow to home address
TOW04	Tow to Manufacturer Approved Repairer
TOW05	Tow to independent Garage
TOW06	Tow to Body Repairer
TOW07	Tow to handover point (relay)

TOW08	Tow to other destination
TOW09	Tow to contractor base for redelivery
TOW10	Tow to contractor base for storage
TOW11	Tow to salvage / vehicle dismantler
TOW12	Safety tow
TOW13	Recovery carried out by Motoring Organisation own resource
TOW14	Refused at Delivery Destination
Others	
NS01	Other: No Trace
NS02	Other: Member Cancelled
NS03	Other: Customer not with vehicle
NS04	Not repaired, recovery required
NS05	Customer making own arrangements